

# LightLEEDer EVO Integrated Relay Panel Installation Details

Installing the LLEVO-INT High Voltage Barrier for powering the panel from 2 sources

1. Fold Voltage Barrier in two spots as shown below, crease to 90 degrees
2. Place the Voltage Barrier between the 4th and 5th relay, secure the flap underneath existing voltage divider and the lip of the enclosure
3. Mount the Barrier to the enclosure using the provided TEK screw

