


LightMaster LAN Node Addressing



- Each networked LightMaster relay control panel must be given a unique 2-digit node address using the addressing switches noted above. Settings from 01 to FF can be used to address up to 255 unique addresses.
- This 2-digit address code system is also used with LightSync data line devices.
- Note all node addresses on the supplied sticker for future reference (they will be needed for programming).