

LonWorks Point Map

Map_Descriptor_Name	Panel Control and Status	SNVT Index	SNVT Type
=====	=====	=====	=====
nvoSMD_DI_10001	Input "On" Read 1	0	SNVT_Switch
nvoSMD_DI_10002	Input "On" Read 2	1	SNVT_Switch
nvoSMD_DI_10003	Input "On" Read 3	2	SNVT_Switch
nvoSMD_DI_10004	Input "On" Read 4	3	SNVT_Switch
nvoSMD_DI_10005	Input "On" Read 5	4	SNVT_Switch
nvoSMD_DI_10006	Input "On" Read 6	5	SNVT_Switch
nvoSMD_DI_10007	Input "On" Read 7	6	SNVT_Switch
nvoSMD_DI_10008	Input "On" Read 8	7	SNVT_Switch
nvoSMD_DI_10009	Input "On" Read 9	8	SNVT_Switch
nvoSMD_DI_10010	Input "On" Read 10	9	SNVT_Switch
nvoSMD_DI_10011	Input "On" Read 11	10	SNVT_Switch
nvoSMD_DI_10012	Input "On" Read 12	11	SNVT_Switch
nvoSMD_DI_10013	Input "On" Read 13	12	SNVT_Switch
nvoSMD_DI_10014	Input "On" Read 14	13	SNVT_Switch
nvoSMD_DI_10015	Input "On" Read 15	14	SNVT_Switch
nvoSMD_DI_10016	Input "On" Read 16	15	SNVT_Switch
nvoSMD_DI_10017	Input "On" Read 17	16	SNVT_Switch
nvoSMD_DI_10018	Input "On" Read 18	17	SNVT_Switch
nvoSMD_DI_10019	Input "On" Read 19	18	SNVT_Switch
nvoSMD_DI_10020	Input "On" Read 20	19	SNVT_Switch
nvoSMD_DI_10021	Input "On" Read 21	20	SNVT_Switch
nvoSMD_DI_10022	Input "On" Read 22	21	SNVT_Switch
nvoSMD_DI_10023	Input "On" Read 23	22	SNVT_Switch
nvoSMD_DI_10024	Input "On" Read 24	23	SNVT_Switch
nvoSMD_DI_10025	Input "On" Read 25	24	SNVT_Switch
nvoSMD_DI_10026	Input "On" Read 26	25	SNVT_Switch
nvoSMD_DI_10027	Input "On" Read 27	26	SNVT_Switch
nvoSMD_DI_10028	Input "On" Read 28	27	SNVT_Switch
nvoSMD_DI_10029	Input "On" Read 29	28	SNVT_Switch
nvoSMD_DI_10030	Input "On" Read 30	29	SNVT_Switch
nvoSMD_DI_10031	Input "On" Read 31	30	SNVT_Switch
nvoSMD_DI_10032	Input "On" Read 32	31	SNVT_Switch
nvoSMD_DI_10033	Input "On" Read 33	32	SNVT_Switch
nvoSMD_DI_10034	Input "On" Read 34	33	SNVT_Switch
nvoSMD_DI_10035	Input "On" Read 35	34	SNVT_Switch
nvoSMD_DI_10036	Input "On" Read 36	35	SNVT_Switch
nvoSMD_DI_10037	Input "On" Read 37	36	SNVT_Switch
nvoSMD_DI_10038	Input "On" Read 38	37	SNVT_Switch
nvoSMD_DI_10039	Input "On" Read 39	38	SNVT_Switch
nvoSMD_DI_10040	Input "On" Read 40	39	SNVT_Switch
nvoSMD_DI_10041	Input "On" Read 41	40	SNVT_Switch
nvoSMD_DI_10042	Input "On" Read 42	41	SNVT_Switch
nvoSMD_DI_10043	Input "On" Read 43	42	SNVT_Switch

nvoSMD_DI_10044	Input "On" Read 44	43	SNVT_Switch
nvoSMD_DI_10045	Input "On" Read 45	44	SNVT_Switch
nvoSMD_DI_10046	Input "On" Read 46	45	SNVT_Switch
nvoSMD_DI_10047	Input "On" Read 47	46	SNVT_Switch
nvoSMD_DI_10048	Input "On" Read 48	47	SNVT_Switch
nvoSMD_DI_10049	Input "Off" Read 1	48	SNVT_Switch
nvoSMD_DI_10050	Input "Off" Read 2	49	SNVT_Switch
nvoSMD_DI_10051	Input "Off" Read 3	50	SNVT_Switch
nvoSMD_DI_10052	Input "Off" Read 4	51	SNVT_Switch
nvoSMD_DI_10053	Input "Off" Read 5	52	SNVT_Switch
nvoSMD_DI_10054	Input "Off" Read 6	53	SNVT_Switch
nvoSMD_DI_10055	Input "Off" Read 7	54	SNVT_Switch
nvoSMD_DI_10056	Input "Off" Read 8	55	SNVT_Switch
nvoSMD_DI_10057	Input "Off" Read 9	56	SNVT_Switch
nvoSMD_DI_10058	Input "Off" Read 10	57	SNVT_Switch
nvoSMD_DI_10059	Input "Off" Read 11	58	SNVT_Switch
nvoSMD_DI_10060	Input "Off" Read 12	59	SNVT_Switch
nvoSMD_DI_10061	Input "Off" Read 13	60	SNVT_Switch
nvoSMD_DI_10062	Input "Off" Read 14	61	SNVT_Switch
nvoSMD_DI_10063	Input "Off" Read 15	62	SNVT_Switch
nvoSMD_DI_10064	Input "Off" Read 16	63	SNVT_Switch
nvoSMD_DI_10065	Input "Off" Read 17	64	SNVT_Switch
nvoSMD_DI_10066	Input "Off" Read 18	65	SNVT_Switch
nvoSMD_DI_10067	Input "Off" Read 19	66	SNVT_Switch
nvoSMD_DI_10068	Input "Off" Read 20	67	SNVT_Switch
nvoSMD_DI_10069	Input "Off" Read 21	68	SNVT_Switch
nvoSMD_DI_10070	Input "Off" Read 22	69	SNVT_Switch
nvoSMD_DI_10071	Input "Off" Read 23	70	SNVT_Switch
nvoSMD_DI_10072	Input "Off" Read 24	71	SNVT_Switch
nvoSMD_DI_10073	Input "Off" Read 25	72	SNVT_Switch
nvoSMD_DI_10074	Input "Off" Read 26	73	SNVT_Switch
nvoSMD_DI_10075	Input "Off" Read 27	74	SNVT_Switch
nvoSMD_DI_10076	Input "Off" Read 28	75	SNVT_Switch
nvoSMD_DI_10077	Input "Off" Read 29	76	SNVT_Switch
nvoSMD_DI_10078	Input "Off" Read 30	77	SNVT_Switch
nvoSMD_DI_10079	Input "Off" Read 31	78	SNVT_Switch
nvoSMD_DI_10080	Input "Off" Read 32	79	SNVT_Switch
nvoSMD_DI_10081	Input "Off" Read 33	80	SNVT_Switch
nvoSMD_DI_10082	Input "Off" Read 34	81	SNVT_Switch
nvoSMD_DI_10083	Input "Off" Read 35	82	SNVT_Switch
nvoSMD_DI_10084	Input "Off" Read 36	83	SNVT_Switch
nvoSMD_DI_10085	Input "Off" Read 37	84	SNVT_Switch
nvoSMD_DI_10086	Input "Off" Read 38	85	SNVT_Switch
nvoSMD_DI_10087	Input "Off" Read 39	86	SNVT_Switch
nvoSMD_DI_10088	Input "Off" Read 40	87	SNVT_Switch
nvoSMD_DI_10089	Input "Off" Read 41	88	SNVT_Switch
nvoSMD_DI_10090	Input "Off" Read 42	89	SNVT_Switch

nvoSMD_DI_10091	Input "Off" Read 43	90	SNVT_Switch
nvoSMD_DI_10092	Input "Off" Read 44	91	SNVT_Switch
nvoSMD_DI_10093	Input "Off" Read 45	92	SNVT_Switch
nvoSMD_DI_10094	Input "Off" Read 46	93	SNVT_Switch
nvoSMD_DI_10095	Input "Off" Read 47	94	SNVT_Switch
nvoSMD_DI_10096	Input "Off" Read 48	95	SNVT_Switch
nvoSMD_DO_00001	Output Read 1	96	SNVT_Switch
nvoSMD_DO_00002	Output Read 2	97	SNVT_Switch
nvoSMD_DO_00003	Output Read 3	98	SNVT_Switch
nvoSMD_DO_00004	Output Read 4	99	SNVT_Switch
nvoSMD_DO_00005	Output Read 5	100	SNVT_Switch
nvoSMD_DO_00006	Output Read 6	101	SNVT_Switch
nvoSMD_DO_00007	Output Read 7	102	SNVT_Switch
nvoSMD_DO_00008	Output Read 8	103	SNVT_Switch
nvoSMD_DO_00009	Output Read 9	104	SNVT_Switch
nvoSMD_DO_00010	Output Read 10	105	SNVT_Switch
nvoSMD_DO_00011	Output Read 11	106	SNVT_Switch
nvoSMD_DO_00012	Output Read 12	107	SNVT_Switch
nvoSMD_DO_00013	Output Read 13	108	SNVT_Switch
nvoSMD_DO_00014	Output Read 14	109	SNVT_Switch
nvoSMD_DO_00015	Output Read 15	110	SNVT_Switch
nvoSMD_DO_00016	Output Read 16	111	SNVT_Switch
nvoSMD_DO_00017	Output Read 17	112	SNVT_Switch
nvoSMD_DO_00018	Output Read 18	113	SNVT_Switch
nvoSMD_DO_00019	Output Read 19	114	SNVT_Switch
nvoSMD_DO_00020	Output Read 20	115	SNVT_Switch
nvoSMD_DO_00021	Output Read 21	116	SNVT_Switch
nvoSMD_DO_00022	Output Read 22	117	SNVT_Switch
nvoSMD_DO_00023	Output Read 23	118	SNVT_Switch
nvoSMD_DO_00024	Output Read 24	119	SNVT_Switch
nvoSMD_DO_00025	Output Read 25	120	SNVT_Switch
nvoSMD_DO_00026	Output Read 26	121	SNVT_Switch
nvoSMD_DO_00027	Output Read 27	122	SNVT_Switch
nvoSMD_DO_00028	Output Read 28	123	SNVT_Switch
nvoSMD_DO_00029	Output Read 29	124	SNVT_Switch
nvoSMD_DO_00030	Output Read 30	125	SNVT_Switch
nvoSMD_DO_00031	Output Read 31	126	SNVT_Switch
nvoSMD_DO_00032	Output Read 32	127	SNVT_Switch
nvoSMD_DO_00033	Output Read 33	128	SNVT_Switch
nvoSMD_DO_00034	Output Read 34	129	SNVT_Switch
nvoSMD_DO_00035	Output Read 35	130	SNVT_Switch
nvoSMD_DO_00036	Output Read 36	131	SNVT_Switch
nvoSMD_DO_00037	Output Read 37	132	SNVT_Switch
nvoSMD_DO_00038	Output Read 38	133	SNVT_Switch
nvoSMD_DO_00039	Output Read 39	134	SNVT_Switch
nvoSMD_DO_00040	Output Read 40	135	SNVT_Switch

nvoSMD_DO_00041	Output Read 41	136	SNVT_Switch
nvoSMD_DO_00042	Output Read 42	137	SNVT_Switch
nvoSMD_DO_00043	Output Read 43	138	SNVT_Switch
nvoSMD_DO_00044	Output Read 44	139	SNVT_Switch
nvoSMD_DO_00045	Output Read 45	140	SNVT_Switch
nvoSMD_DO_00046	Output Read 46	141	SNVT_Switch
nvoSMD_DO_00047	Output Read 47	142	SNVT_Switch
nvoSMD_DO_00048	Output Read 48	143	SNVT_Switch
nvoSMD_DO_00101	Output Timer Option Read 1	144	SNVT_Switch
nvoSMD_DO_00102	Output Timer Option Read 2	145	SNVT_Switch
nvoSMD_DO_00103	Output Timer Option Read 3	146	SNVT_Switch
nvoSMD_DO_00104	Output Timer Option Read 4	147	SNVT_Switch
nvoSMD_DO_00105	Output Timer Option Read 5	148	SNVT_Switch
nvoSMD_DO_00106	Output Timer Option Read 6	149	SNVT_Switch
nvoSMD_DO_00107	Output Timer Option Read 7	150	SNVT_Switch
nvoSMD_DO_00108	Output Timer Option Read 8	151	SNVT_Switch
nvoSMD_DO_00109	Output Timer Option Read 9	152	SNVT_Switch
nvoSMD_DO_00110	Output Timer Option Read 10	153	SNVT_Switch
nvoSMD_DO_00111	Output Timer Option Read 11	154	SNVT_Switch
nvoSMD_DO_00112	Output Timer Option Read 12	155	SNVT_Switch
nvoSMD_DO_00113	Output Timer Option Read 13	156	SNVT_Switch
nvoSMD_DO_00114	Output Timer Option Read 14	157	SNVT_Switch
nvoSMD_DO_00115	Output Timer Option Read 15	158	SNVT_Switch
nvoSMD_DO_00116	Output Timer Option Read 16	159	SNVT_Switch
nvoSMD_DO_00117	Output Timer Option Read 17	160	SNVT_Switch
nvoSMD_DO_00118	Output Timer Option Read 18	161	SNVT_Switch
nvoSMD_DO_00119	Output Timer Option Read 19	162	SNVT_Switch
nvoSMD_DO_00120	Output Timer Option Read 20	163	SNVT_Switch
nvoSMD_DO_00121	Output Timer Option Read 21	164	SNVT_Switch
nvoSMD_DO_00122	Output Timer Option Read 22	165	SNVT_Switch
nvoSMD_DO_00123	Output Timer Option Read 23	166	SNVT_Switch
nvoSMD_DO_00124	Output Timer Option Read 24	167	SNVT_Switch
nvoSMD_DO_00125	Output Timer Option Read 25	168	SNVT_Switch
nvoSMD_DO_00126	Output Timer Option Read 26	169	SNVT_Switch
nvoSMD_DO_00127	Output Timer Option Read 27	170	SNVT_Switch
nvoSMD_DO_00128	Output Timer Option Read 28	171	SNVT_Switch
nvoSMD_DO_00129	Output Timer Option Read 29	172	SNVT_Switch
nvoSMD_DO_00130	Output Timer Option Read 30	173	SNVT_Switch
nvoSMD_DO_00131	Output Timer Option Read 31	174	SNVT_Switch
nvoSMD_DO_00132	Output Timer Option Read 32	175	SNVT_Switch
nvoSMD_DO_00133	Output Timer Option Read 33	176	SNVT_Switch
nvoSMD_DO_00134	Output Timer Option Read 34	177	SNVT_Switch
nvoSMD_DO_00135	Output Timer Option Read 35	178	SNVT_Switch
nvoSMD_DO_00136	Output Timer Option Read 36	179	SNVT_Switch
nvoSMD_DO_00137	Output Timer Option Read 37	180	SNVT_Switch
nvoSMD_DO_00138	Output Timer Option Read 38	181	SNVT_Switch

nvoSMD_DO_00139	Output Timer Option Read 39	182	SNVT_Switch
nvoSMD_DO_00140	Output Timer Option Read 40	183	SNVT_Switch
nvoSMD_DO_00141	Output Timer Option Read 41	184	SNVT_Switch
nvoSMD_DO_00142	Output Timer Option Read 42	185	SNVT_Switch
nvoSMD_DO_00143	Output Timer Option Read 43	186	SNVT_Switch
nvoSMD_DO_00144	Output Timer Option Read 44	187	SNVT_Switch
nvoSMD_DO_00145	Output Timer Option Read 45	188	SNVT_Switch
nvoSMD_DO_00146	Output Timer Option Read 46	189	SNVT_Switch
nvoSMD_DO_00147	Output Timer Option Read 47	190	SNVT_Switch
nvoSMD_DO_00148	Output Timer Option Read 48	191	SNVT_Switch
nvoSMD_DO_00201	Input Disable Read 1	192	SNVT_Switch
nvoSMD_DO_00202	Input Disable Read 2	193	SNVT_Switch
nvoSMD_DO_00203	Input Disable Read 3	194	SNVT_Switch
nvoSMD_DO_00204	Input Disable Read 4	195	SNVT_Switch
nvoSMD_DO_00205	Input Disable Read 5	196	SNVT_Switch
nvoSMD_DO_00206	Input Disable Read 6	197	SNVT_Switch
nvoSMD_DO_00207	Input Disable Read 7	198	SNVT_Switch
nvoSMD_DO_00208	Input Disable Read 8	199	SNVT_Switch
nvoSMD_DO_00209	Input Disable Read 9	200	SNVT_Switch
nvoSMD_DO_00210	Input Disable Read 10	201	SNVT_Switch
nvoSMD_DO_00211	Input Disable Read 11	202	SNVT_Switch
nvoSMD_DO_00212	Input Disable Read 12	203	SNVT_Switch
nvoSMD_DO_00213	Input Disable Read 13	204	SNVT_Switch
nvoSMD_DO_00214	Input Disable Read 14	205	SNVT_Switch
nvoSMD_DO_00215	Input Disable Read 15	206	SNVT_Switch
nvoSMD_DO_00216	Input Disable Read 16	207	SNVT_Switch
nvoSMD_DO_00217	Input Disable Read 17	208	SNVT_Switch
nvoSMD_DO_00218	Input Disable Read 18	209	SNVT_Switch
nvoSMD_DO_00219	Input Disable Read 19	210	SNVT_Switch
nvoSMD_DO_00220	Input Disable Read 20	211	SNVT_Switch
nvoSMD_DO_00221	Input Disable Read 21	212	SNVT_Switch
nvoSMD_DO_00222	Input Disable Read 22	213	SNVT_Switch
nvoSMD_DO_00223	Input Disable Read 23	214	SNVT_Switch
nvoSMD_DO_00224	Input Disable Read 24	215	SNVT_Switch
nvoSMD_DO_00225	Input Disable Read 25	216	SNVT_Switch
nvoSMD_DO_00226	Input Disable Read 26	217	SNVT_Switch
nvoSMD_DO_00227	Input Disable Read 27	218	SNVT_Switch
nvoSMD_DO_00228	Input Disable Read 28	219	SNVT_Switch
nvoSMD_DO_00229	Input Disable Read 29	220	SNVT_Switch
nvoSMD_DO_00230	Input Disable Read 30	221	SNVT_Switch
nvoSMD_DO_00231	Input Disable Read 31	222	SNVT_Switch
nvoSMD_DO_00232	Input Disable Read 32	223	SNVT_Switch
nvoSMD_DO_00233	Input Disable Read 33	224	SNVT_Switch
nvoSMD_DO_00234	Input Disable Read 34	225	SNVT_Switch
nvoSMD_DO_00235	Input Disable Read 35	226	SNVT_Switch
nvoSMD_DO_00236	Input Disable Read 36	227	SNVT_Switch

nvoSMD_DO_00237	Input Disable Read 37	228	SNVT_Switch
nvoSMD_DO_00238	Input Disable Read 38	229	SNVT_Switch
nvoSMD_DO_00239	Input Disable Read 39	230	SNVT_Switch
nvoSMD_DO_00240	Input Disable Read 40	231	SNVT_Switch
nvoSMD_DO_00241	Input Disable Read 41	232	SNVT_Switch
nvoSMD_DO_00242	Input Disable Read 42	233	SNVT_Switch
nvoSMD_DO_00243	Input Disable Read 43	234	SNVT_Switch
nvoSMD_DO_00244	Input Disable Read 44	235	SNVT_Switch
nvoSMD_DO_00245	Input Disable Read 45	236	SNVT_Switch
nvoSMD_DO_00246	Input Disable Read 46	237	SNVT_Switch
nvoSMD_DO_00247	Input Disable Read 47	238	SNVT_Switch
nvoSMD_DO_00248	Input Disable Read 48	239	SNVT_Switch
nviSMD_DO_00001	Output Write 1	240	SNVT_Switch
nviSMD_DO_00002	Output Write 2	241	SNVT_Switch
nviSMD_DO_00003	Output Write 3	242	SNVT_Switch
nviSMD_DO_00004	Output Write 4	243	SNVT_Switch
nviSMD_DO_00005	Output Write 5	244	SNVT_Switch
nviSMD_DO_00006	Output Write 6	245	SNVT_Switch
nviSMD_DO_00007	Output Write 7	246	SNVT_Switch
nviSMD_DO_00008	Output Write 8	247	SNVT_Switch
nviSMD_DO_00009	Output Write 9	248	SNVT_Switch
nviSMD_DO_00010	Output Write 10	249	SNVT_Switch
nviSMD_DO_00011	Output Write 11	250	SNVT_Switch
nviSMD_DO_00012	Output Write 12	251	SNVT_Switch
nviSMD_DO_00013	Output Write 13	252	SNVT_Switch
nviSMD_DO_00014	Output Write 14	253	SNVT_Switch
nviSMD_DO_00015	Output Write 15	254	SNVT_Switch
nviSMD_DO_00016	Output Write 16	255	SNVT_Switch
nviSMD_DO_00017	Output Write 17	256	SNVT_Switch
nviSMD_DO_00018	Output Write 18	257	SNVT_Switch
nviSMD_DO_00019	Output Write 19	258	SNVT_Switch
nviSMD_DO_00020	Output Write 20	259	SNVT_Switch
nviSMD_DO_00021	Output Write 21	260	SNVT_Switch
nviSMD_DO_00022	Output Write 22	261	SNVT_Switch
nviSMD_DO_00023	Output Write 23	262	SNVT_Switch
nviSMD_DO_00024	Output Write 24	263	SNVT_Switch
nviSMD_DO_00025	Output Write 25	264	SNVT_Switch
nviSMD_DO_00026	Output Write 26	265	SNVT_Switch
nviSMD_DO_00027	Output Write 27	266	SNVT_Switch
nviSMD_DO_00028	Output Write 28	267	SNVT_Switch
nviSMD_DO_00029	Output Write 29	268	SNVT_Switch
nviSMD_DO_00030	Output Write 30	269	SNVT_Switch
nviSMD_DO_00031	Output Write 31	270	SNVT_Switch
nviSMD_DO_00032	Output Write 32	271	SNVT_Switch
nviSMD_DO_00033	Output Write 33	272	SNVT_Switch
nviSMD_DO_00034	Output Write 34	273	SNVT_Switch

nviSMD_DO_00035	Output Write 35	274	SNVT_Switch
nviSMD_DO_00036	Output Write 36	275	SNVT_Switch
nviSMD_DO_00037	Output Write 37	276	SNVT_Switch
nviSMD_DO_00038	Output Write 38	277	SNVT_Switch
nviSMD_DO_00039	Output Write 39	278	SNVT_Switch
nviSMD_DO_00040	Output Write 40	279	SNVT_Switch
nviSMD_DO_00041	Output Write 41	280	SNVT_Switch
nviSMD_DO_00042	Output Write 42	281	SNVT_Switch
nviSMD_DO_00043	Output Write 43	282	SNVT_Switch
nviSMD_DO_00044	Output Write 44	283	SNVT_Switch
nviSMD_DO_00045	Output Write 45	284	SNVT_Switch
nviSMD_DO_00046	Output Write 46	285	SNVT_Switch
nviSMD_DO_00047	Output Write 47	286	SNVT_Switch
nviSMD_DO_00048	Output Write 48	287	SNVT_Switch

nviSMD_DO_00101	Output Timer Option Write 1	288	SNVT_Switch
nviSMD_DO_00102	Output Timer Option Write 2	289	SNVT_Switch
nviSMD_DO_00103	Output Timer Option Write 3	290	SNVT_Switch
nviSMD_DO_00104	Output Timer Option Write 4	291	SNVT_Switch
nviSMD_DO_00105	Output Timer Option Write 5	292	SNVT_Switch
nviSMD_DO_00106	Output Timer Option Write 6	293	SNVT_Switch
nviSMD_DO_00107	Output Timer Option Write 7	294	SNVT_Switch
nviSMD_DO_00108	Output Timer Option Write 8	295	SNVT_Switch
nviSMD_DO_00109	Output Timer Option Write 9	296	SNVT_Switch
nviSMD_DO_00110	Output Timer Option Write 10	297	SNVT_Switch
nviSMD_DO_00111	Output Timer Option Write 11	298	SNVT_Switch
nviSMD_DO_00112	Output Timer Option Write 12	299	SNVT_Switch
nviSMD_DO_00113	Output Timer Option Write 13	300	SNVT_Switch
nviSMD_DO_00114	Output Timer Option Write 14	301	SNVT_Switch
nviSMD_DO_00115	Output Timer Option Write 15	302	SNVT_Switch
nviSMD_DO_00116	Output Timer Option Write 16	303	SNVT_Switch
nviSMD_DO_00117	Output Timer Option Write 17	304	SNVT_Switch
nviSMD_DO_00118	Output Timer Option Write 18	305	SNVT_Switch
nviSMD_DO_00119	Output Timer Option Write 19	306	SNVT_Switch
nviSMD_DO_00120	Output Timer Option Write 20	307	SNVT_Switch
nviSMD_DO_00121	Output Timer Option Write 21	308	SNVT_Switch
nviSMD_DO_00122	Output Timer Option Write 22	309	SNVT_Switch
nviSMD_DO_00123	Output Timer Option Write 23	310	SNVT_Switch
nviSMD_DO_00124	Output Timer Option Write 24	311	SNVT_Switch
nviSMD_DO_00125	Output Timer Option Write 25	312	SNVT_Switch
nviSMD_DO_00126	Output Timer Option Write 26	313	SNVT_Switch
nviSMD_DO_00127	Output Timer Option Write 27	314	SNVT_Switch
nviSMD_DO_00128	Output Timer Option Write 28	315	SNVT_Switch
nviSMD_DO_00129	Output Timer Option Write 29	316	SNVT_Switch
nviSMD_DO_00130	Output Timer Option Write 30	317	SNVT_Switch
nviSMD_DO_00131	Output Timer Option Write 31	318	SNVT_Switch
nviSMD_DO_00132	Output Timer Option Write 32	319	SNVT_Switch

nviSMD_DO_00133	Output Timer Option Write 33	320	SNVT_Switch
nviSMD_DO_00134	Output Timer Option Write 34	321	SNVT_Switch
nviSMD_DO_00135	Output Timer Option Write 35	322	SNVT_Switch
nviSMD_DO_00136	Output Timer Option Write 36	323	SNVT_Switch
nviSMD_DO_00137	Output Timer Option Write 37	324	SNVT_Switch
nviSMD_DO_00138	Output Timer Option Write 38	325	SNVT_Switch
nviSMD_DO_00139	Output Timer Option Write 39	326	SNVT_Switch
nviSMD_DO_00140	Output Timer Option Write 40	327	SNVT_Switch
nviSMD_DO_00141	Output Timer Option Write 41	328	SNVT_Switch
nviSMD_DO_00142	Output Timer Option Write 42	329	SNVT_Switch
nviSMD_DO_00143	Output Timer Option Write 43	330	SNVT_Switch
nviSMD_DO_00144	Output Timer Option Write 44	331	SNVT_Switch
nviSMD_DO_00145	Output Timer Option Write 45	332	SNVT_Switch
nviSMD_DO_00146	Output Timer Option Write 46	333	SNVT_Switch
nviSMD_DO_00147	Output Timer Option Write 47	334	SNVT_Switch
nviSMD_DO_00148	Output Timer Option Write 48	335	SNVT_Switch

nviSMD_DO_00201	Input Disable Write 1	336	SNVT_Switch
nviSMD_DO_00202	Input Disable Write 2	337	SNVT_Switch
nviSMD_DO_00203	Input Disable Write 3	338	SNVT_Switch
nviSMD_DO_00204	Input Disable Write 4	339	SNVT_Switch
nviSMD_DO_00205	Input Disable Write 5	340	SNVT_Switch
nviSMD_DO_00206	Input Disable Write 6	341	SNVT_Switch
nviSMD_DO_00207	Input Disable Write 7	342	SNVT_Switch
nviSMD_DO_00208	Input Disable Write 8	343	SNVT_Switch
nviSMD_DO_00209	Input Disable Write 9	344	SNVT_Switch
nviSMD_DO_00210	Input Disable Write 10	345	SNVT_Switch
nviSMD_DO_00211	Input Disable Write 11	346	SNVT_Switch
nviSMD_DO_00212	Input Disable Write 12	347	SNVT_Switch
nviSMD_DO_00213	Input Disable Write 13	348	SNVT_Switch
nviSMD_DO_00214	Input Disable Write 14	349	SNVT_Switch
nviSMD_DO_00215	Input Disable Write 15	350	SNVT_Switch
nviSMD_DO_00216	Input Disable Write 16	351	SNVT_Switch
nviSMD_DO_00217	Input Disable Write 17	352	SNVT_Switch
nviSMD_DO_00218	Input Disable Write 18	353	SNVT_Switch
nviSMD_DO_00219	Input Disable Write 19	354	SNVT_Switch
nviSMD_DO_00220	Input Disable Write 20	355	SNVT_Switch
nviSMD_DO_00221	Input Disable Write 21	356	SNVT_Switch
nviSMD_DO_00222	Input Disable Write 22	357	SNVT_Switch
nviSMD_DO_00223	Input Disable Write 23	358	SNVT_Switch
nviSMD_DO_00224	Input Disable Write 24	359	SNVT_Switch
nviSMD_DO_00225	Input Disable Write 25	360	SNVT_Switch
nviSMD_DO_00226	Input Disable Write 26	361	SNVT_Switch
nviSMD_DO_00227	Input Disable Write 27	362	SNVT_Switch
nviSMD_DO_00228	Input Disable Write 28	363	SNVT_Switch
nviSMD_DO_00229	Input Disable Write 29	364	SNVT_Switch
nviSMD_DO_00230	Input Disable Write 30	365	SNVT_Switch

nviSMD_DO_00231	Input Disable Write 31	366	SNVT_Switch
nviSMD_DO_00232	Input Disable Write 32	367	SNVT_Switch
nviSMD_DO_00233	Input Disable Write 33	368	SNVT_Switch
nviSMD_DO_00234	Input Disable Write 34	369	SNVT_Switch
nviSMD_DO_00235	Input Disable Write 35	370	SNVT_Switch
nviSMD_DO_00236	Input Disable Write 36	371	SNVT_Switch
nviSMD_DO_00237	Input Disable Write 37	372	SNVT_Switch
nviSMD_DO_00238	Input Disable Write 38	373	SNVT_Switch
nviSMD_DO_00239	Input Disable Write 39	374	SNVT_Switch
nviSMD_DO_00240	Input Disable Write 40	375	SNVT_Switch
nviSMD_DO_00241	Input Disable Write 41	376	SNVT_Switch
nviSMD_DO_00242	Input Disable Write 42	377	SNVT_Switch
nviSMD_DO_00243	Input Disable Write 43	378	SNVT_Switch
nviSMD_DO_00244	Input Disable Write 44	379	SNVT_Switch
nviSMD_DO_00245	Input Disable Write 45	380	SNVT_Switch
nviSMD_DO_00246	Input Disable Write 46	381	SNVT_Switch
nviSMD_DO_00247	Input Disable Write 47	382	SNVT_Switch
nviSMD_DO_00248	Input Disable Write 48	383	SNVT_Switch