


# Metasys® N2 Serial Interface



## General

- Use Metasys N2 control protocol
- Connects directly to the N2 Metasys RS 485 bus
- Allows status reporting and direct control of relays

## Programming

- The LightMaster must be equipped with a N2 add-on module that is addressed with a unique node address. The network cable is a RS 485 two wire shielded twisted pair
- Once plugged into the lighting control panel, BAS software can be programmed to control relays in the LightMaster panel
- All local control features for the relay panel will continue to be operable

## N2 Control

- Only BI and BO point types are used.

## Physical

- Plug-in module designed for mounting to LightMaster main board

## Operating Environment

- Location Interior space
- Operating Temperature 0° to 50° C (32° to 112° F)
- Relative Humidity 10% to 90% Non-Condensing

## Certifications

- UL
- FCC Approval for commercial and residential use

## Configuration

- Soft configuration