

LightLEEDer EVO Integrated Relay Panel Installation Details

Installing the LightLEEDer EVO Integrated Relay Panel:

- Place the enclosure in an easy to access location near the loads to be controlled.
- Typically panels are mounted in the room to be controlled.
- The panel should be mounted indoors at an ambient temperature of 0 - 50° C (32°-122°F) and a humidity of 10 - 90% non-condensing.
- Secure enclosure to desired surface using the four pre-drilled mounting holes and appropriate hardware.
- Terminate to high voltage leads as indicated below, cap off any unused leads. See WD0614 for more details.
- Set panel address for network applications and test each device as they are connected.
- Secure enclosure cover using four cover plate holes and provided hardware.

