Catalog Number: Date: Project:



www.ilc-usa.com

Light**LEED**er

**Pro Software** 

#### **Overview**

The LightLEEDer Pro software provides Windows-based software that simplifies programming of stand-alone or networked LightLEEDer systems. Simply connect directly using a USB cable or through a network TCP/IP connection on a LAN or WAN and you're ready to program the system. Software also allows you to monitor relays, inputs, presets, and groups or control relays with a simple click of your mouse. Programming can be accomplished online or offline and files can be saved for backup.



### **Features**

- Made in the USA
- Windows-based lighting control programming software
- Web access via virtual sever
- Complimentary software with the purchase of a panel
- Diagnostics built in for panels and devices
- Programming can be done on or offline
- Graphical interface with point-and-click commands
- Program all LightLEEDer functions

- Simplifies programming
- Connect via USB, TCP/IP, or modem
- Save/Open programming files to a hard drive for backup and restore
- Documentation feature for printing or diagnosing programming issues
- Compatible for stand-alone or networked systems

## Warranty

Six-year limited warranty

# **Ordering**

Software downloadable from ILC web site

Catalog Number: Date: Project:




www.ilc-usa.com


Light**LEED**er

**Pro Software** 

# **Physical**



Relay Options



**Timer Configuration** 

### **Specifications**

#### **Programming Capabilities:**

- **System Settings:** Set up panels, LightSync devices, dimmers, motor controls, serial Interfaces, naming, diagnostics, and clear memory
- Clock Functions: Set the time and date, longitude and latitude, and daylight saving time
- Time Based Functions: Timer schedules are set for time-of-day, astro time, or an open-close time. Timers to relays/groups, timed-on, blink alerts, alarms, and off-hour sweeps.
- **Relay Configuration:** Relay type and lock option, output timer, power-up options, relay conditionals, relay groups, relay presets, and input to relay mapping
- Input Configuration: Configure device types, input types, input conditionals, active times, and pilots

#### **Suggested Minimum System Requirements:**

- PC or laptop
- 2Ghz dual core
- · Windows 10 Pro, 64 bit
- USB 2.0
- •8G RAM
- SVGA monitor 1024 x 768
- 10/100 Ethernet adapter

#### **Connection Options:**

- USB 2.0
- TCP/IP 10/100
- · Web access via virtual sever