

## LightLEEDer-EVO-4X, -8X Mapping

Address Switch Setting	A		A & B	
	EVO-4X Relays	EVO-4X Dimmers	EVO-8X Relays	EVO-8X Dimmers
1	01-04	01.1-4	01-08	01.1-4, 02.1-4
2	05-08	02.1-4	05-12	02.1-4, 03.1-4
3	09-12	03.1-4	09-16	03.1-4, 04.1-4
4	13-16	04.1-4	13-20	04.1-4, 05.1-4
5	17-20	05.1-4	17-24	05.1-4, 06.1-4
6	21-24	06.1-4	21-28	06.1-4, 07.1-4
7	25-28	07.1-4	25-32	07.1-4, 08.1-4
8	29-32	08.1-4	29-36	08.1-4, 09.1-4
9	33-36	09.1-4	33-40	09.1-4, 0A.1-4
A	37-40	0A.1-4	37-44	0A.1-4, 0B.1-4
B	41-44	0B.1-4	41-48	0B.1-4, 0C.1-4
C	45-48	0C.1-4	45-52	0C.1-4, 0D.1-4
D	49-52	0D.1-4	49-56	0D.1-4, 0E.1-4
E	53-56	0E.1-4	53-60	0E.1-4, 0F.1-4
F	57-60	0F.1-4	57-64	0F.1-4, 10.1-4
0	61-64	10.1-4	Invalid	Invalid

Modules are factory built as a 4X or 8X controller. Refer to the columns for the device supplied.