

LightLEEDer InSite BACnet-IP Control Point Mapping

InSite Group, Preset, or Sequence Status and control

Object ID	InSite Point Name	Type	InSite Control	Function
1	InSite Control Point 001	DO	InSite Control 001	Status and On/Off Control
2	InSite Control Point 002	DO	InSite Control 002	Status and On/Off Control
3	InSite Control Point 003	DO	InSite Control 003	Status and On/Off Control
4	InSite Control Point 004	DO	InSite Control 004	Status and On/Off Control
5	InSite Control Point 005	DO	InSite Control 005	Status and On/Off Control
6	InSite Control Point 006	DO	InSite Control 006	Status and On/Off Control
7	InSite Control Point 007	DO	InSite Control 007	Status and On/Off Control
8	InSite Control Point 008	DO	InSite Control 008	Status and On/Off Control
9	InSite Control Point 009	DO	InSite Control 009	Status and On/Off Control
10	InSite Control Point 010	DO	InSite Control 010	Status and On/Off Control
11	InSite Control Point 011	DO	InSite Control 011	Status and On/Off Control
12	InSite Control Point 012	DO	InSite Control 012	Status and On/Off Control
13	InSite Control Point 013	DO	InSite Control 013	Status and On/Off Control
14	InSite Control Point 014	DO	InSite Control 014	Status and On/Off Control
15	InSite Control Point 015	DO	InSite Control 015	Status and On/Off Control
16	InSite Control Point 016	DO	InSite Control 016	Status and On/Off Control
17	InSite Control Point 017	DO	InSite Control 017	Status and On/Off Control
18	InSite Control Point 018	DO	InSite Control 018	Status and On/Off Control
19	InSite Control Point 019	DO	InSite Control 019	Status and On/Off Control
20	InSite Control Point 020	DO	InSite Control 020	Status and On/Off Control
21	InSite Control Point 021	DO	InSite Control 021	Status and On/Off Control
22	InSite Control Point 022	DO	InSite Control 022	Status and On/Off Control
23	InSite Control Point 023	DO	InSite Control 023	Status and On/Off Control
24	InSite Control Point 024	DO	InSite Control 024	Status and On/Off Control
25	InSite Control Point 025	DO	InSite Control 025	Status and On/Off Control
26	InSite Control Point 026	DO	InSite Control 026	Status and On/Off Control
27	InSite Control Point 027	DO	InSite Control 027	Status and On/Off Control
28	InSite Control Point 028	DO	InSite Control 028	Status and On/Off Control
29	InSite Control Point 029	DO	InSite Control 029	Status and On/Off Control
30	InSite Control Point 030	DO	InSite Control 030	Status and On/Off Control
31	InSite Control Point 031	DO	InSite Control 031	Status and On/Off Control
32	InSite Control Point 032	DO	InSite Control 032	Status and On/Off Control
33	InSite Control Point 033	DO	InSite Control 033	Status and On/Off Control
34	InSite Control Point 034	DO	InSite Control 034	Status and On/Off Control
35	InSite Control Point 035	DO	InSite Control 035	Status and On/Off Control
36	InSite Control Point 036	DO	InSite Control 036	Status and On/Off Control
37	InSite Control Point 037	DO	InSite Control 037	Status and On/Off Control
38	InSite Control Point 038	DO	InSite Control 038	Status and On/Off Control
39	InSite Control Point 039	DO	InSite Control 039	Status and On/Off Control
40	InSite Control Point 040	DO	InSite Control 040	Status and On/Off Control

41	InSite Control Point 041	DO	InSite Control 041	Status and On/Off Control
42	InSite Control Point 042	DO	InSite Control 042	Status and On/Off Control
43	InSite Control Point 043	DO	InSite Control 043	Status and On/Off Control
44	InSite Control Point 044	DO	InSite Control 044	Status and On/Off Control
45	InSite Control Point 045	DO	InSite Control 045	Status and On/Off Control
46	InSite Control Point 046	DO	InSite Control 046	Status and On/Off Control
47	InSite Control Point 047	DO	InSite Control 047	Status and On/Off Control
48	InSite Control Point 048	DO	InSite Control 048	Status and On/Off Control
49	InSite Control Point 049	DO	InSite Control 049	Status and On/Off Control
50	InSite Control Point 050	DO	InSite Control 050	Status and On/Off Control
51	InSite Control Point 051	DO	InSite Control 051	Status and On/Off Control
52	InSite Control Point 052	DO	InSite Control 052	Status and On/Off Control
53	InSite Control Point 053	DO	InSite Control 053	Status and On/Off Control
54	InSite Control Point 054	DO	InSite Control 054	Status and On/Off Control
55	InSite Control Point 055	DO	InSite Control 055	Status and On/Off Control
56	InSite Control Point 056	DO	InSite Control 056	Status and On/Off Control
57	InSite Control Point 057	DO	InSite Control 057	Status and On/Off Control
58	InSite Control Point 058	DO	InSite Control 058	Status and On/Off Control
59	InSite Control Point 059	DO	InSite Control 059	Status and On/Off Control
60	InSite Control Point 060	DO	InSite Control 060	Status and On/Off Control
61	InSite Control Point 061	DO	InSite Control 061	Status and On/Off Control
62	InSite Control Point 062	DO	InSite Control 062	Status and On/Off Control
63	InSite Control Point 063	DO	InSite Control 063	Status and On/Off Control
64	InSite Control Point 064	DO	InSite Control 064	Status and On/Off Control
65	InSite Control Point 065	DO	InSite Control 065	Status and On/Off Control
66	InSite Control Point 066	DO	InSite Control 066	Status and On/Off Control
67	InSite Control Point 067	DO	InSite Control 067	Status and On/Off Control
68	InSite Control Point 068	DO	InSite Control 068	Status and On/Off Control
69	InSite Control Point 069	DO	InSite Control 069	Status and On/Off Control
70	InSite Control Point 070	DO	InSite Control 070	Status and On/Off Control
71	InSite Control Point 071	DO	InSite Control 071	Status and On/Off Control
72	InSite Control Point 072	DO	InSite Control 072	Status and On/Off Control
73	InSite Control Point 073	DO	InSite Control 073	Status and On/Off Control
74	InSite Control Point 074	DO	InSite Control 074	Status and On/Off Control
75	InSite Control Point 075	DO	InSite Control 075	Status and On/Off Control
76	InSite Control Point 076	DO	InSite Control 076	Status and On/Off Control
77	InSite Control Point 077	DO	InSite Control 077	Status and On/Off Control
78	InSite Control Point 078	DO	InSite Control 078	Status and On/Off Control
79	InSite Control Point 079	DO	InSite Control 079	Status and On/Off Control
80	InSite Control Point 080	DO	InSite Control 080	Status and On/Off Control
81	InSite Control Point 081	DO	InSite Control 081	Status and On/Off Control
82	InSite Control Point 082	DO	InSite Control 082	Status and On/Off Control
83	InSite Control Point 083	DO	InSite Control 083	Status and On/Off Control
84	InSite Control Point 084	DO	InSite Control 084	Status and On/Off Control
85	InSite Control Point 085	DO	InSite Control 085	Status and On/Off Control

86	InSite Control Point 086	DO	InSite Control 086	Status and On/Off Control
87	InSite Control Point 087	DO	InSite Control 087	Status and On/Off Control
88	InSite Control Point 088	DO	InSite Control 088	Status and On/Off Control
89	InSite Control Point 089	DO	InSite Control 089	Status and On/Off Control
90	InSite Control Point 090	DO	InSite Control 090	Status and On/Off Control
91	InSite Control Point 091	DO	InSite Control 091	Status and On/Off Control
92	InSite Control Point 092	DO	InSite Control 092	Status and On/Off Control
93	InSite Control Point 093	DO	InSite Control 093	Status and On/Off Control
94	InSite Control Point 094	DO	InSite Control 094	Status and On/Off Control
95	InSite Control Point 095	DO	InSite Control 095	Status and On/Off Control
96	InSite Control Point 096	DO	InSite Control 096	Status and On/Off Control
97	InSite Control Point 097	DO	InSite Control 097	Status and On/Off Control
98	InSite Control Point 098	DO	InSite Control 098	Status and On/Off Control
99	InSite Control Point 099	DO	InSite Control 099	Status and On/Off Control
100	InSite Control Point 100	DO	InSite Control 100	Status and On/Off Control
101	InSite Control Point 101	DO	InSite Control 101	Status and On/Off Control
102	InSite Control Point 102	DO	InSite Control 102	Status and On/Off Control
103	InSite Control Point 103	DO	InSite Control 103	Status and On/Off Control
104	InSite Control Point 104	DO	InSite Control 104	Status and On/Off Control
105	InSite Control Point 105	DO	InSite Control 105	Status and On/Off Control
106	InSite Control Point 106	DO	InSite Control 106	Status and On/Off Control
107	InSite Control Point 107	DO	InSite Control 107	Status and On/Off Control
108	InSite Control Point 108	DO	InSite Control 108	Status and On/Off Control
109	InSite Control Point 109	DO	InSite Control 109	Status and On/Off Control
110	InSite Control Point 110	DO	InSite Control 110	Status and On/Off Control
111	InSite Control Point 111	DO	InSite Control 111	Status and On/Off Control
112	InSite Control Point 112	DO	InSite Control 112	Status and On/Off Control
113	InSite Control Point 113	DO	InSite Control 113	Status and On/Off Control
114	InSite Control Point 114	DO	InSite Control 114	Status and On/Off Control
115	InSite Control Point 115	DO	InSite Control 115	Status and On/Off Control
116	InSite Control Point 116	DO	InSite Control 116	Status and On/Off Control
117	InSite Control Point 117	DO	InSite Control 117	Status and On/Off Control
118	InSite Control Point 118	DO	InSite Control 118	Status and On/Off Control
119	InSite Control Point 119	DO	InSite Control 119	Status and On/Off Control
120	InSite Control Point 120	DO	InSite Control 120	Status and On/Off Control
121	InSite Control Point 121	DO	InSite Control 121	Status and On/Off Control
122	InSite Control Point 122	DO	InSite Control 122	Status and On/Off Control
123	InSite Control Point 123	DO	InSite Control 123	Status and On/Off Control
124	InSite Control Point 124	DO	InSite Control 124	Status and On/Off Control
125	InSite Control Point 125	DO	InSite Control 125	Status and On/Off Control
126	InSite Control Point 126	DO	InSite Control 126	Status and On/Off Control
127	InSite Control Point 127	DO	InSite Control 127	Status and On/Off Control
128	InSite Control Point 128	DO	InSite Control 128	Status and On/Off Control
129	InSite Control Point 129	DO	InSite Control 129	Status and On/Off Control
130	InSite Control Point 130	DO	InSite Control 130	Status and On/Off Control

134	InSite Control Point 134	DO	InSite Control 134	Status and On/Off Control
135	InSite Control Point 135	DO	InSite Control 135	Status and On/Off Control
136	InSite Control Point 136	DO	InSite Control 136	Status and On/Off Control
137	InSite Control Point 137	DO	InSite Control 137	Status and On/Off Control
138	InSite Control Point 138	DO	InSite Control 138	Status and On/Off Control
139	InSite Control Point 139	DO	InSite Control 139	Status and On/Off Control
140	InSite Control Point 140	DO	InSite Control 140	Status and On/Off Control
141	InSite Control Point 141	DO	InSite Control 141	Status and On/Off Control
142	InSite Control Point 142	DO	InSite Control 142	Status and On/Off Control
143	InSite Control Point 143	DO	InSite Control 143	Status and On/Off Control
144	InSite Control Point 144	DO	InSite Control 144	Status and On/Off Control
145	InSite Control Point 145	DO	InSite Control 145	Status and On/Off Control
146	InSite Control Point 146	DO	InSite Control 146	Status and On/Off Control
147	InSite Control Point 147	DO	InSite Control 147	Status and On/Off Control
148	InSite Control Point 148	DO	InSite Control 148	Status and On/Off Control
149	InSite Control Point 149	DO	InSite Control 149	Status and On/Off Control
150	InSite Control Point 150	DO	InSite Control 150	Status and On/Off Control
151	InSite Control Point 151	DO	InSite Control 151	Status and On/Off Control
152	InSite Control Point 152	DO	InSite Control 152	Status and On/Off Control
153	InSite Control Point 153	DO	InSite Control 153	Status and On/Off Control
154	InSite Control Point 154	DO	InSite Control 154	Status and On/Off Control
155	InSite Control Point 155	DO	InSite Control 155	Status and On/Off Control
156	InSite Control Point 156	DO	InSite Control 156	Status and On/Off Control
157	InSite Control Point 157	DO	InSite Control 157	Status and On/Off Control
158	InSite Control Point 158	DO	InSite Control 158	Status and On/Off Control
159	InSite Control Point 159	DO	InSite Control 159	Status and On/Off Control
160	InSite Control Point 160	DO	InSite Control 160	Status and On/Off Control
161	InSite Control Point 161	DO	InSite Control 161	Status and On/Off Control
162	InSite Control Point 162	DO	InSite Control 162	Status and On/Off Control
163	InSite Control Point 163	DO	InSite Control 163	Status and On/Off Control
164	InSite Control Point 164	DO	InSite Control 164	Status and On/Off Control
165	InSite Control Point 165	DO	InSite Control 165	Status and On/Off Control
166	InSite Control Point 166	DO	InSite Control 166	Status and On/Off Control
167	InSite Control Point 167	DO	InSite Control 167	Status and On/Off Control
168	InSite Control Point 168	DO	InSite Control 168	Status and On/Off Control
169	InSite Control Point 169	DO	InSite Control 169	Status and On/Off Control
170	InSite Control Point 170	DO	InSite Control 170	Status and On/Off Control
171	InSite Control Point 171	DO	InSite Control 171	Status and On/Off Control
172	InSite Control Point 172	DO	InSite Control 172	Status and On/Off Control
173	InSite Control Point 173	DO	InSite Control 173	Status and On/Off Control
174	InSite Control Point 174	DO	InSite Control 174	Status and On/Off Control
175	InSite Control Point 175	DO	InSite Control 175	Status and On/Off Control
176	InSite Control Point 176	DO	InSite Control 176	Status and On/Off Control
177	InSite Control Point 177	DO	InSite Control 177	Status and On/Off Control
178	InSite Control Point 178	DO	InSite Control 178	Status and On/Off Control

182	InSite Control Point 182	DO	InSite Control 182	Status and On/Off Control
183	InSite Control Point 183	DO	InSite Control 183	Status and On/Off Control
184	InSite Control Point 184	DO	InSite Control 184	Status and On/Off Control
185	InSite Control Point 185	DO	InSite Control 185	Status and On/Off Control
186	InSite Control Point 186	DO	InSite Control 186	Status and On/Off Control
187	InSite Control Point 187	DO	InSite Control 187	Status and On/Off Control
188	InSite Control Point 188	DO	InSite Control 188	Status and On/Off Control
189	InSite Control Point 189	DO	InSite Control 189	Status and On/Off Control
190	InSite Control Point 190	DO	InSite Control 190	Status and On/Off Control
191	InSite Control Point 191	DO	InSite Control 191	Status and On/Off Control
192	InSite Control Point 192	DO	InSite Control 192	Status and On/Off Control
193	InSite Control Point 193	DO	InSite Control 193	Status and On/Off Control
194	InSite Control Point 194	DO	InSite Control 194	Status and On/Off Control
195	InSite Control Point 195	DO	InSite Control 195	Status and On/Off Control
196	InSite Control Point 196	DO	InSite Control 196	Status and On/Off Control
197	InSite Control Point 197	DO	InSite Control 197	Status and On/Off Control
198	InSite Control Point 198	DO	InSite Control 198	Status and On/Off Control
199	InSite Control Point 199	DO	InSite Control 199	Status and On/Off Control
200	InSite Control Point 200	DO	InSite Control 200	Status and On/Off Control
201	InSite Control Point 201	DO	InSite Control 201	Status and On/Off Control
202	InSite Control Point 202	DO	InSite Control 202	Status and On/Off Control
203	InSite Control Point 203	DO	InSite Control 203	Status and On/Off Control
204	InSite Control Point 204	DO	InSite Control 204	Status and On/Off Control
205	InSite Control Point 205	DO	InSite Control 205	Status and On/Off Control
206	InSite Control Point 206	DO	InSite Control 206	Status and On/Off Control
207	InSite Control Point 207	DO	InSite Control 207	Status and On/Off Control
208	InSite Control Point 208	DO	InSite Control 208	Status and On/Off Control
209	InSite Control Point 209	DO	InSite Control 209	Status and On/Off Control
210	InSite Control Point 210	DO	InSite Control 210	Status and On/Off Control
211	InSite Control Point 211	DO	InSite Control 211	Status and On/Off Control
212	InSite Control Point 212	DO	InSite Control 212	Status and On/Off Control
213	InSite Control Point 213	DO	InSite Control 213	Status and On/Off Control
214	InSite Control Point 214	DO	InSite Control 214	Status and On/Off Control
215	InSite Control Point 215	DO	InSite Control 215	Status and On/Off Control
216	InSite Control Point 216	DO	InSite Control 216	Status and On/Off Control
217	InSite Control Point 217	DO	InSite Control 217	Status and On/Off Control
218	InSite Control Point 218	DO	InSite Control 218	Status and On/Off Control
219	InSite Control Point 219	DO	InSite Control 219	Status and On/Off Control
220	InSite Control Point 220	DO	InSite Control 220	Status and On/Off Control
221	InSite Control Point 221	DO	InSite Control 221	Status and On/Off Control
222	InSite Control Point 222	DO	InSite Control 222	Status and On/Off Control
223	InSite Control Point 223	DO	InSite Control 223	Status and On/Off Control
224	InSite Control Point 224	DO	InSite Control 224	Status and On/Off Control
225	InSite Control Point 225	DO	InSite Control 225	Status and On/Off Control
226	InSite Control Point 226	DO	InSite Control 226	Status and On/Off Control

272	InSite Control Point 273	DO	InSite Control 273	Status and On/Off Control
273	InSite Control Point 274	DO	InSite Control 274	Status and On/Off Control
274	InSite Control Point 275	DO	InSite Control 275	Status and On/Off Control
275	InSite Control Point 276	DO	InSite Control 276	Status and On/Off Control
276	InSite Control Point 277	DO	InSite Control 277	Status and On/Off Control
277	InSite Control Point 278	DO	InSite Control 278	Status and On/Off Control
278	InSite Control Point 279	DO	InSite Control 279	Status and On/Off Control
279	InSite Control Point 280	DO	InSite Control 280	Status and On/Off Control
280	InSite Control Point 281	DO	InSite Control 281	Status and On/Off Control
281	InSite Control Point 282	DO	InSite Control 282	Status and On/Off Control
282	InSite Control Point 283	DO	InSite Control 283	Status and On/Off Control
283	InSite Control Point 284	DO	InSite Control 284	Status and On/Off Control
284	InSite Control Point 285	DO	InSite Control 285	Status and On/Off Control
285	InSite Control Point 286	DO	InSite Control 286	Status and On/Off Control
286	InSite Control Point 287	DO	InSite Control 287	Status and On/Off Control
287	InSite Control Point 288	DO	InSite Control 288	Status and On/Off Control
288	InSite Control Point 289	DO	InSite Control 289	Status and On/Off Control
289	InSite Control Point 290	DO	InSite Control 290	Status and On/Off Control
290	InSite Control Point 291	DO	InSite Control 291	Status and On/Off Control
291	InSite Control Point 292	DO	InSite Control 292	Status and On/Off Control
292	InSite Control Point 293	DO	InSite Control 293	Status and On/Off Control
293	InSite Control Point 294	DO	InSite Control 294	Status and On/Off Control
294	InSite Control Point 295	DO	InSite Control 295	Status and On/Off Control
295	InSite Control Point 296	DO	InSite Control 296	Status and On/Off Control
296	InSite Control Point 297	DO	InSite Control 297	Status and On/Off Control
297	InSite Control Point 298	DO	InSite Control 298	Status and On/Off Control
298	InSite Control Point 299	DO	InSite Control 299	Status and On/Off Control
299	InSite Control Point 300	DO	InSite Control 300	Status and On/Off Control
300	InSite Control Point 301	DO	InSite Control 301	Status and On/Off Control
301	InSite Control Point 302	DO	InSite Control 302	Status and On/Off Control
302	InSite Control Point 303	DO	InSite Control 303	Status and On/Off Control
303	InSite Control Point 304	DO	InSite Control 304	Status and On/Off Control
304	InSite Control Point 305	DO	InSite Control 305	Status and On/Off Control
305	InSite Control Point 306	DO	InSite Control 306	Status and On/Off Control
306	InSite Control Point 307	DO	InSite Control 307	Status and On/Off Control
307	InSite Control Point 308	DO	InSite Control 308	Status and On/Off Control
308	InSite Control Point 309	DO	InSite Control 309	Status and On/Off Control
309	InSite Control Point 310	DO	InSite Control 310	Status and On/Off Control
310	InSite Control Point 311	DO	InSite Control 311	Status and On/Off Control
311	InSite Control Point 312	DO	InSite Control 312	Status and On/Off Control
312	InSite Control Point 313	DO	InSite Control 313	Status and On/Off Control
313	InSite Control Point 314	DO	InSite Control 314	Status and On/Off Control
314	InSite Control Point 315	DO	InSite Control 315	Status and On/Off Control
315	InSite Control Point 316	DO	InSite Control 316	Status and On/Off Control
316	InSite Control Point 317	DO	InSite Control 317	Status and On/Off Control

317	InSite Control Point 317	DO	InSite Control 317	Status and On/Off Control
318	InSite Control Point 318	DO	InSite Control 318	Status and On/Off Control
319	InSite Control Point 319	DO	InSite Control 319	Status and On/Off Control
320	InSite Control Point 320	DO	InSite Control 320	Status and On/Off Control
321	InSite Control Point 321	DO	InSite Control 321	Status and On/Off Control
322	InSite Control Point 322	DO	InSite Control 322	Status and On/Off Control
323	InSite Control Point 323	DO	InSite Control 323	Status and On/Off Control
324	InSite Control Point 324	DO	InSite Control 324	Status and On/Off Control
325	InSite Control Point 325	DO	InSite Control 325	Status and On/Off Control
326	InSite Control Point 326	DO	InSite Control 326	Status and On/Off Control
327	InSite Control Point 327	DO	InSite Control 327	Status and On/Off Control
328	InSite Control Point 328	DO	InSite Control 328	Status and On/Off Control
329	InSite Control Point 329	DO	InSite Control 329	Status and On/Off Control
330	InSite Control Point 330	DO	InSite Control 330	Status and On/Off Control
331	InSite Control Point 331	DO	InSite Control 331	Status and On/Off Control
332	InSite Control Point 332	DO	InSite Control 332	Status and On/Off Control
333	InSite Control Point 333	DO	InSite Control 333	Status and On/Off Control
334	InSite Control Point 334	DO	InSite Control 334	Status and On/Off Control
335	InSite Control Point 335	DO	InSite Control 335	Status and On/Off Control
336	InSite Control Point 336	DO	InSite Control 336	Status and On/Off Control
337	InSite Control Point 337	DO	InSite Control 337	Status and On/Off Control
338	InSite Control Point 338	DO	InSite Control 338	Status and On/Off Control
339	InSite Control Point 339	DO	InSite Control 339	Status and On/Off Control
340	InSite Control Point 340	DO	InSite Control 340	Status and On/Off Control
341	InSite Control Point 341	DO	InSite Control 341	Status and On/Off Control
342	InSite Control Point 342	DO	InSite Control 342	Status and On/Off Control
343	InSite Control Point 343	DO	InSite Control 343	Status and On/Off Control
344	InSite Control Point 344	DO	InSite Control 344	Status and On/Off Control
345	InSite Control Point 345	DO	InSite Control 345	Status and On/Off Control
346	InSite Control Point 346	DO	InSite Control 346	Status and On/Off Control
347	InSite Control Point 347	DO	InSite Control 347	Status and On/Off Control
348	InSite Control Point 348	DO	InSite Control 348	Status and On/Off Control
349	InSite Control Point 349	DO	InSite Control 349	Status and On/Off Control
350	InSite Control Point 350	DO	InSite Control 350	Status and On/Off Control
351	InSite Control Point 351	DO	InSite Control 351	Status and On/Off Control
352	InSite Control Point 352	DO	InSite Control 352	Status and On/Off Control
353	InSite Control Point 353	DO	InSite Control 353	Status and On/Off Control
354	InSite Control Point 354	DO	InSite Control 354	Status and On/Off Control
355	InSite Control Point 355	DO	InSite Control 355	Status and On/Off Control
356	InSite Control Point 356	DO	InSite Control 356	Status and On/Off Control
357	InSite Control Point 357	DO	InSite Control 357	Status and On/Off Control
358	InSite Control Point 358	DO	InSite Control 358	Status and On/Off Control
359	InSite Control Point 359	DO	InSite Control 359	Status and On/Off Control
360	InSite Control Point 360	DO	InSite Control 360	Status and On/Off Control
361	InSite Control Point 361	DO	InSite Control 361	Status and On/Off Control

362	InSite Control Point 362	DO	InSite Control 362	Status and On/Off Control
363	InSite Control Point 363	DO	InSite Control 363	Status and On/Off Control
364	InSite Control Point 364	DO	InSite Control 364	Status and On/Off Control
365	InSite Control Point 365	DO	InSite Control 365	Status and On/Off Control
366	InSite Control Point 366	DO	InSite Control 366	Status and On/Off Control
367	InSite Control Point 367	DO	InSite Control 367	Status and On/Off Control
368	InSite Control Point 368	DO	InSite Control 368	Status and On/Off Control
369	InSite Control Point 369	DO	InSite Control 369	Status and On/Off Control
370	InSite Control Point 370	DO	InSite Control 370	Status and On/Off Control
371	InSite Control Point 371	DO	InSite Control 371	Status and On/Off Control
372	InSite Control Point 372	DO	InSite Control 372	Status and On/Off Control
373	InSite Control Point 373	DO	InSite Control 373	Status and On/Off Control
374	InSite Control Point 374	DO	InSite Control 374	Status and On/Off Control
375	InSite Control Point 375	DO	InSite Control 375	Status and On/Off Control
376	InSite Control Point 376	DO	InSite Control 376	Status and On/Off Control
377	InSite Control Point 377	DO	InSite Control 377	Status and On/Off Control
378	InSite Control Point 378	DO	InSite Control 378	Status and On/Off Control
379	InSite Control Point 379	DO	InSite Control 379	Status and On/Off Control
380	InSite Control Point 380	DO	InSite Control 380	Status and On/Off Control
381	InSite Control Point 381	DO	InSite Control 381	Status and On/Off Control
382	InSite Control Point 382	DO	InSite Control 382	Status and On/Off Control
383	InSite Control Point 383	DO	InSite Control 383	Status and On/Off Control
384	InSite Control Point 384	DO	InSite Control 384	Status and On/Off Control
385	InSite Control Point 385	DO	InSite Control 385	Status and On/Off Control
386	InSite Control Point 386	DO	InSite Control 386	Status and On/Off Control
387	InSite Control Point 387	DO	InSite Control 387	Status and On/Off Control
388	InSite Control Point 388	DO	InSite Control 388	Status and On/Off Control
389	InSite Control Point 389	DO	InSite Control 389	Status and On/Off Control
390	InSite Control Point 390	DO	InSite Control 390	Status and On/Off Control
391	InSite Control Point 391	DO	InSite Control 391	Status and On/Off Control
392	InSite Control Point 392	DO	InSite Control 392	Status and On/Off Control
393	InSite Control Point 393	DO	InSite Control 393	Status and On/Off Control
394	InSite Control Point 394	DO	InSite Control 394	Status and On/Off Control
395	InSite Control Point 395	DO	InSite Control 395	Status and On/Off Control
396	InSite Control Point 396	DO	InSite Control 396	Status and On/Off Control
397	InSite Control Point 397	DO	InSite Control 397	Status and On/Off Control
398	InSite Control Point 398	DO	InSite Control 398	Status and On/Off Control
399	InSite Control Point 399	DO	InSite Control 399	Status and On/Off Control
400	InSite Control Point 400	DO	InSite Control 400	Status and On/Off Control
401	InSite Control Point 401	DO	InSite Control 401	Status and On/Off Control
402	InSite Control Point 402	DO	InSite Control 402	Status and On/Off Control
403	InSite Control Point 403	DO	InSite Control 403	Status and On/Off Control
404	InSite Control Point 404	DO	InSite Control 404	Status and On/Off Control
405	InSite Control Point 405	DO	InSite Control 405	Status and On/Off Control
406	InSite Control Point 406	DO	InSite Control 406	Status and On/Off Control

452	InSite Control Point 452	DO	InSite Control 452	Status and On/Off Control
453	InSite Control Point 453	DO	InSite Control 453	Status and On/Off Control
454	InSite Control Point 454	DO	InSite Control 454	Status and On/Off Control
455	InSite Control Point 455	DO	InSite Control 455	Status and On/Off Control
456	InSite Control Point 456	DO	InSite Control 456	Status and On/Off Control
457	InSite Control Point 457	DO	InSite Control 457	Status and On/Off Control
458	InSite Control Point 458	DO	InSite Control 458	Status and On/Off Control
459	InSite Control Point 459	DO	InSite Control 459	Status and On/Off Control
460	InSite Control Point 460	DO	InSite Control 460	Status and On/Off Control
461	InSite Control Point 461	DO	InSite Control 461	Status and On/Off Control
462	InSite Control Point 462	DO	InSite Control 462	Status and On/Off Control
463	InSite Control Point 463	DO	InSite Control 463	Status and On/Off Control
464	InSite Control Point 464	DO	InSite Control 464	Status and On/Off Control
465	InSite Control Point 465	DO	InSite Control 465	Status and On/Off Control
466	InSite Control Point 466	DO	InSite Control 466	Status and On/Off Control
467	InSite Control Point 467	DO	InSite Control 467	Status and On/Off Control
468	InSite Control Point 468	DO	InSite Control 468	Status and On/Off Control
469	InSite Control Point 469	DO	InSite Control 469	Status and On/Off Control
470	InSite Control Point 470	DO	InSite Control 470	Status and On/Off Control
471	InSite Control Point 471	DO	InSite Control 471	Status and On/Off Control
472	InSite Control Point 472	DO	InSite Control 472	Status and On/Off Control
473	InSite Control Point 473	DO	InSite Control 473	Status and On/Off Control
474	InSite Control Point 474	DO	InSite Control 474	Status and On/Off Control
475	InSite Control Point 475	DO	InSite Control 475	Status and On/Off Control
476	InSite Control Point 476	DO	InSite Control 476	Status and On/Off Control
477	InSite Control Point 477	DO	InSite Control 477	Status and On/Off Control
478	InSite Control Point 478	DO	InSite Control 478	Status and On/Off Control
479	InSite Control Point 479	DO	InSite Control 479	Status and On/Off Control
480	InSite Control Point 480	DO	InSite Control 480	Status and On/Off Control
481	InSite Control Point 481	DO	InSite Control 481	Status and On/Off Control
482	InSite Control Point 482	DO	InSite Control 482	Status and On/Off Control
483	InSite Control Point 483	DO	InSite Control 483	Status and On/Off Control
484	InSite Control Point 484	DO	InSite Control 484	Status and On/Off Control
485	InSite Control Point 485	DO	InSite Control 485	Status and On/Off Control
486	InSite Control Point 486	DO	InSite Control 486	Status and On/Off Control
487	InSite Control Point 487	DO	InSite Control 487	Status and On/Off Control
488	InSite Control Point 488	DO	InSite Control 488	Status and On/Off Control
489	InSite Control Point 489	DO	InSite Control 489	Status and On/Off Control
490	InSite Control Point 490	DO	InSite Control 490	Status and On/Off Control
491	InSite Control Point 491	DO	InSite Control 491	Status and On/Off Control
492	InSite Control Point 492	DO	InSite Control 492	Status and On/Off Control
493	InSite Control Point 493	DO	InSite Control 493	Status and On/Off Control
494	InSite Control Point 494	DO	InSite Control 494	Status and On/Off Control
495	InSite Control Point 495	DO	InSite Control 495	Status and On/Off Control
496	InSite Control Point 496	DO	InSite Control 496	Status and On/Off Control

542	InSite Control Point 542	DO	InSite Control 542	Status and On/Off Control
543	InSite Control Point 543	DO	InSite Control 543	Status and On/Off Control
544	InSite Control Point 544	DO	InSite Control 544	Status and On/Off Control
545	InSite Control Point 545	DO	InSite Control 545	Status and On/Off Control
546	InSite Control Point 546	DO	InSite Control 546	Status and On/Off Control
547	InSite Control Point 547	DO	InSite Control 547	Status and On/Off Control
548	InSite Control Point 548	DO	InSite Control 548	Status and On/Off Control
549	InSite Control Point 549	DO	InSite Control 549	Status and On/Off Control
550	InSite Control Point 550	DO	InSite Control 550	Status and On/Off Control
551	InSite Control Point 551	DO	InSite Control 551	Status and On/Off Control
552	InSite Control Point 552	DO	InSite Control 552	Status and On/Off Control
553	InSite Control Point 553	DO	InSite Control 553	Status and On/Off Control
554	InSite Control Point 554	DO	InSite Control 554	Status and On/Off Control
555	InSite Control Point 555	DO	InSite Control 555	Status and On/Off Control
556	InSite Control Point 556	DO	InSite Control 556	Status and On/Off Control
557	InSite Control Point 557	DO	InSite Control 557	Status and On/Off Control
558	InSite Control Point 558	DO	InSite Control 558	Status and On/Off Control
559	InSite Control Point 559	DO	InSite Control 559	Status and On/Off Control
560	InSite Control Point 560	DO	InSite Control 560	Status and On/Off Control
561	InSite Control Point 561	DO	InSite Control 561	Status and On/Off Control
562	InSite Control Point 562	DO	InSite Control 562	Status and On/Off Control
563	InSite Control Point 563	DO	InSite Control 563	Status and On/Off Control
564	InSite Control Point 564	DO	InSite Control 564	Status and On/Off Control
565	InSite Control Point 565	DO	InSite Control 565	Status and On/Off Control
566	InSite Control Point 566	DO	InSite Control 566	Status and On/Off Control
567	InSite Control Point 567	DO	InSite Control 567	Status and On/Off Control
568	InSite Control Point 568	DO	InSite Control 568	Status and On/Off Control
569	InSite Control Point 569	DO	InSite Control 569	Status and On/Off Control
570	InSite Control Point 570	DO	InSite Control 570	Status and On/Off Control
571	InSite Control Point 571	DO	InSite Control 571	Status and On/Off Control
572	InSite Control Point 572	DO	InSite Control 572	Status and On/Off Control
573	InSite Control Point 573	DO	InSite Control 573	Status and On/Off Control
574	InSite Control Point 574	DO	InSite Control 574	Status and On/Off Control
575	InSite Control Point 575	DO	InSite Control 575	Status and On/Off Control
576	InSite Control Point 576	DO	InSite Control 576	Status and On/Off Control
577	InSite Control Point 577	DO	InSite Control 577	Status and On/Off Control
578	InSite Control Point 578	DO	InSite Control 578	Status and On/Off Control
579	InSite Control Point 579	DO	InSite Control 579	Status and On/Off Control
580	InSite Control Point 580	DO	InSite Control 580	Status and On/Off Control
581	InSite Control Point 581	DO	InSite Control 581	Status and On/Off Control
582	InSite Control Point 582	DO	InSite Control 582	Status and On/Off Control
583	InSite Control Point 583	DO	InSite Control 583	Status and On/Off Control
584	InSite Control Point 584	DO	InSite Control 584	Status and On/Off Control
585	InSite Control Point 585	DO	InSite Control 585	Status and On/Off Control
586	InSite Control Point 586	DO	InSite Control 586	Status and On/Off Control

587	InSite Control Point 587	DO	InSite Control 587	Status and On/Off Control
588	InSite Control Point 588	DO	InSite Control 588	Status and On/Off Control
589	InSite Control Point 589	DO	InSite Control 589	Status and On/Off Control
590	InSite Control Point 590	DO	InSite Control 590	Status and On/Off Control
591	InSite Control Point 591	DO	InSite Control 591	Status and On/Off Control
592	InSite Control Point 592	DO	InSite Control 592	Status and On/Off Control
593	InSite Control Point 593	DO	InSite Control 593	Status and On/Off Control
594	InSite Control Point 594	DO	InSite Control 594	Status and On/Off Control
595	InSite Control Point 595	DO	InSite Control 595	Status and On/Off Control
596	InSite Control Point 596	DO	InSite Control 596	Status and On/Off Control
597	InSite Control Point 597	DO	InSite Control 597	Status and On/Off Control
598	InSite Control Point 598	DO	InSite Control 598	Status and On/Off Control
599	InSite Control Point 599	DO	InSite Control 599	Status and On/Off Control
600	InSite Control Point 600	DO	InSite Control 600	Status and On/Off Control
601	InSite Control Point 601	DO	InSite Control 601	Status and On/Off Control
602	InSite Control Point 602	DO	InSite Control 602	Status and On/Off Control
603	InSite Control Point 603	DO	InSite Control 603	Status and On/Off Control
604	InSite Control Point 604	DO	InSite Control 604	Status and On/Off Control
605	InSite Control Point 605	DO	InSite Control 605	Status and On/Off Control
606	InSite Control Point 606	DO	InSite Control 606	Status and On/Off Control
607	InSite Control Point 607	DO	InSite Control 607	Status and On/Off Control
608	InSite Control Point 608	DO	InSite Control 608	Status and On/Off Control
609	InSite Control Point 609	DO	InSite Control 609	Status and On/Off Control
610	InSite Control Point 610	DO	InSite Control 610	Status and On/Off Control
611	InSite Control Point 611	DO	InSite Control 611	Status and On/Off Control
612	InSite Control Point 612	DO	InSite Control 612	Status and On/Off Control
613	InSite Control Point 613	DO	InSite Control 613	Status and On/Off Control
614	InSite Control Point 614	DO	InSite Control 614	Status and On/Off Control
615	InSite Control Point 615	DO	InSite Control 615	Status and On/Off Control
616	InSite Control Point 616	DO	InSite Control 616	Status and On/Off Control
617	InSite Control Point 617	DO	InSite Control 617	Status and On/Off Control
618	InSite Control Point 618	DO	InSite Control 618	Status and On/Off Control
619	InSite Control Point 619	DO	InSite Control 619	Status and On/Off Control
620	InSite Control Point 620	DO	InSite Control 620	Status and On/Off Control
621	InSite Control Point 621	DO	InSite Control 621	Status and On/Off Control
622	InSite Control Point 622	DO	InSite Control 622	Status and On/Off Control
623	InSite Control Point 623	DO	InSite Control 623	Status and On/Off Control
624	InSite Control Point 624	DO	InSite Control 624	Status and On/Off Control
625	InSite Control Point 625	DO	InSite Control 625	Status and On/Off Control
626	InSite Control Point 626	DO	InSite Control 626	Status and On/Off Control
627	InSite Control Point 627	DO	InSite Control 627	Status and On/Off Control
628	InSite Control Point 628	DO	InSite Control 628	Status and On/Off Control
629	InSite Control Point 629	DO	InSite Control 629	Status and On/Off Control
630	InSite Control Point 630	DO	InSite Control 630	Status and On/Off Control
631	InSite Control Point 631	DO	InSite Control 631	Status and On/Off Control

632	InSite Control Point 632	DO	InSite Control 632	Status and On/Off Control
633	InSite Control Point 633	DO	InSite Control 633	Status and On/Off Control
634	InSite Control Point 634	DO	InSite Control 634	Status and On/Off Control
635	InSite Control Point 635	DO	InSite Control 635	Status and On/Off Control
636	InSite Control Point 636	DO	InSite Control 636	Status and On/Off Control
637	InSite Control Point 637	DO	InSite Control 637	Status and On/Off Control
638	InSite Control Point 638	DO	InSite Control 638	Status and On/Off Control
639	InSite Control Point 639	DO	InSite Control 639	Status and On/Off Control
640	InSite Control Point 640	DO	InSite Control 640	Status and On/Off Control
641	InSite Control Point 641	DO	InSite Control 641	Status and On/Off Control
642	InSite Control Point 642	DO	InSite Control 642	Status and On/Off Control
643	InSite Control Point 643	DO	InSite Control 643	Status and On/Off Control
644	InSite Control Point 644	DO	InSite Control 644	Status and On/Off Control
645	InSite Control Point 645	DO	InSite Control 645	Status and On/Off Control
646	InSite Control Point 646	DO	InSite Control 646	Status and On/Off Control
647	InSite Control Point 647	DO	InSite Control 647	Status and On/Off Control
648	InSite Control Point 648	DO	InSite Control 648	Status and On/Off Control
649	InSite Control Point 649	DO	InSite Control 649	Status and On/Off Control
650	InSite Control Point 650	DO	InSite Control 650	Status and On/Off Control
651	InSite Control Point 651	DO	InSite Control 651	Status and On/Off Control
652	InSite Control Point 652	DO	InSite Control 652	Status and On/Off Control
653	InSite Control Point 653	DO	InSite Control 653	Status and On/Off Control
654	InSite Control Point 654	DO	InSite Control 654	Status and On/Off Control
655	InSite Control Point 655	DO	InSite Control 655	Status and On/Off Control
656	InSite Control Point 656	DO	InSite Control 656	Status and On/Off Control
657	InSite Control Point 657	DO	InSite Control 657	Status and On/Off Control
658	InSite Control Point 658	DO	InSite Control 658	Status and On/Off Control
659	InSite Control Point 659	DO	InSite Control 659	Status and On/Off Control
660	InSite Control Point 660	DO	InSite Control 660	Status and On/Off Control
661	InSite Control Point 661	DO	InSite Control 661	Status and On/Off Control
662	InSite Control Point 662	DO	InSite Control 662	Status and On/Off Control
663	InSite Control Point 663	DO	InSite Control 663	Status and On/Off Control
664	InSite Control Point 664	DO	InSite Control 664	Status and On/Off Control
665	InSite Control Point 665	DO	InSite Control 665	Status and On/Off Control
666	InSite Control Point 666	DO	InSite Control 666	Status and On/Off Control
667	InSite Control Point 667	DO	InSite Control 667	Status and On/Off Control
668	InSite Control Point 668	DO	InSite Control 668	Status and On/Off Control
669	InSite Control Point 669	DO	InSite Control 669	Status and On/Off Control
670	InSite Control Point 670	DO	InSite Control 670	Status and On/Off Control
671	InSite Control Point 671	DO	InSite Control 671	Status and On/Off Control
672	InSite Control Point 672	DO	InSite Control 672	Status and On/Off Control
673	InSite Control Point 673	DO	InSite Control 673	Status and On/Off Control
674	InSite Control Point 674	DO	InSite Control 674	Status and On/Off Control
675	InSite Control Point 675	DO	InSite Control 675	Status and On/Off Control
676	InSite Control Point 676	DO	InSite Control 676	Status and On/Off Control

677	InSite Control Point 677	DO	InSite Control 677	Status and On/Off Control
678	InSite Control Point 678	DO	InSite Control 678	Status and On/Off Control
679	InSite Control Point 679	DO	InSite Control 679	Status and On/Off Control
680	InSite Control Point 680	DO	InSite Control 680	Status and On/Off Control
681	InSite Control Point 681	DO	InSite Control 681	Status and On/Off Control
682	InSite Control Point 682	DO	InSite Control 682	Status and On/Off Control
683	InSite Control Point 683	DO	InSite Control 683	Status and On/Off Control
684	InSite Control Point 684	DO	InSite Control 684	Status and On/Off Control
685	InSite Control Point 685	DO	InSite Control 685	Status and On/Off Control
686	InSite Control Point 686	DO	InSite Control 686	Status and On/Off Control
687	InSite Control Point 687	DO	InSite Control 687	Status and On/Off Control
688	InSite Control Point 688	DO	InSite Control 688	Status and On/Off Control
689	InSite Control Point 689	DO	InSite Control 689	Status and On/Off Control
690	InSite Control Point 690	DO	InSite Control 690	Status and On/Off Control
691	InSite Control Point 691	DO	InSite Control 691	Status and On/Off Control
692	InSite Control Point 692	DO	InSite Control 692	Status and On/Off Control
693	InSite Control Point 693	DO	InSite Control 693	Status and On/Off Control
694	InSite Control Point 694	DO	InSite Control 694	Status and On/Off Control
695	InSite Control Point 695	DO	InSite Control 695	Status and On/Off Control
696	InSite Control Point 696	DO	InSite Control 696	Status and On/Off Control
697	InSite Control Point 697	DO	InSite Control 697	Status and On/Off Control
698	InSite Control Point 698	DO	InSite Control 698	Status and On/Off Control
699	InSite Control Point 699	DO	InSite Control 699	Status and On/Off Control
700	InSite Control Point 700	DO	InSite Control 700	Status and On/Off Control
701	InSite Control Point 701	DO	InSite Control 701	Status and On/Off Control
702	InSite Control Point 702	DO	InSite Control 702	Status and On/Off Control
703	InSite Control Point 703	DO	InSite Control 703	Status and On/Off Control
704	InSite Control Point 704	DO	InSite Control 704	Status and On/Off Control
705	InSite Control Point 705	DO	InSite Control 705	Status and On/Off Control
706	InSite Control Point 706	DO	InSite Control 706	Status and On/Off Control
707	InSite Control Point 707	DO	InSite Control 707	Status and On/Off Control
708	InSite Control Point 708	DO	InSite Control 708	Status and On/Off Control
709	InSite Control Point 709	DO	InSite Control 709	Status and On/Off Control
710	InSite Control Point 710	DO	InSite Control 710	Status and On/Off Control
711	InSite Control Point 711	DO	InSite Control 711	Status and On/Off Control
712	InSite Control Point 712	DO	InSite Control 712	Status and On/Off Control
713	InSite Control Point 713	DO	InSite Control 713	Status and On/Off Control
714	InSite Control Point 714	DO	InSite Control 714	Status and On/Off Control
715	InSite Control Point 715	DO	InSite Control 715	Status and On/Off Control
716	InSite Control Point 716	DO	InSite Control 716	Status and On/Off Control
717	InSite Control Point 717	DO	InSite Control 717	Status and On/Off Control
718	InSite Control Point 718	DO	InSite Control 718	Status and On/Off Control
719	InSite Control Point 719	DO	InSite Control 719	Status and On/Off Control
720	InSite Control Point 720	DO	InSite Control 720	Status and On/Off Control
721	InSite Control Point 721	DO	InSite Control 721	Status and On/Off Control
722	InSite Control Point 722	DO	InSite Control 722	Status and On/Off Control

723	InSite Control Point 723	DO	InSite Control 723	Status and On/Off Control
724	InSite Control Point 724	DO	InSite Control 724	Status and On/Off Control
725	InSite Control Point 725	DO	InSite Control 725	Status and On/Off Control
726	InSite Control Point 726	DO	InSite Control 726	Status and On/Off Control
727	InSite Control Point 727	DO	InSite Control 727	Status and On/Off Control
728	InSite Control Point 728	DO	InSite Control 728	Status and On/Off Control
729	InSite Control Point 729	DO	InSite Control 729	Status and On/Off Control
730	InSite Control Point 730	DO	InSite Control 730	Status and On/Off Control
731	InSite Control Point 731	DO	InSite Control 731	Status and On/Off Control
732	InSite Control Point 732	DO	InSite Control 732	Status and On/Off Control
733	InSite Control Point 733	DO	InSite Control 733	Status and On/Off Control
734	InSite Control Point 734	DO	InSite Control 734	Status and On/Off Control
735	InSite Control Point 735	DO	InSite Control 735	Status and On/Off Control
736	InSite Control Point 736	DO	InSite Control 736	Status and On/Off Control
737	InSite Control Point 737	DO	InSite Control 737	Status and On/Off Control
738	InSite Control Point 738	DO	InSite Control 738	Status and On/Off Control
739	InSite Control Point 739	DO	InSite Control 739	Status and On/Off Control
740	InSite Control Point 740	DO	InSite Control 740	Status and On/Off Control
741	InSite Control Point 741	DO	InSite Control 741	Status and On/Off Control
742	InSite Control Point 742	DO	InSite Control 742	Status and On/Off Control
743	InSite Control Point 743	DO	InSite Control 743	Status and On/Off Control
744	InSite Control Point 744	DO	InSite Control 744	Status and On/Off Control
745	InSite Control Point 745	DO	InSite Control 745	Status and On/Off Control
746	InSite Control Point 746	DO	InSite Control 746	Status and On/Off Control
747	InSite Control Point 747	DO	InSite Control 747	Status and On/Off Control
748	InSite Control Point 748	DO	InSite Control 748	Status and On/Off Control
749	InSite Control Point 749	DO	InSite Control 749	Status and On/Off Control
750	InSite Control Point 750	DO	InSite Control 750	Status and On/Off Control