


LightLEEDer EVO Wireless Wiring Details



- Wire the LightLEEDer EVO Wireless controller to 120 or 277VAC power within range of the wireless devices to be controlled.
- Wireless devices are linked to the LLEVO-W controller using a 915Mhz radio signal within a 50 foot line of sight range.
- Connect CAT-5 data cable from the ILC data network and set the panel address switches for networking the LLEVO-W. Refer to network layout for panel address information.
- Link the remote LSG3-W switches and wireless relays to the controller to create a wireless panel system.
- For linking the LLEVO-W to wireless devices see TB0402