
-2, -4, -8 Relay Panel Photo Sensor Wiring Details



RJ45 Terminal Adaptor Wiring

- Install the CAT-5 cable from the LLEVO-INT panel to the photosensor location in the ceiling near a window.
- Use a junction box if required for plenum ceiling.
- Plug the RJ-45 terminal adaptor on to the CAT-5.
- Strip and cut the photo sensor wire 0.50 inches.
- Insert into terminals 2, 3, 4 as shown above.
- Normal distance to a Photosensor should be 35 to 50 feet. If the the distance exceeds 100 feet terminate the sensor wires to ports 1 and 2 (Red), ports 3 and 6 (Black), and ports 7 and 8 (Blue) using a pair of wires in the CAT-5 cable to increasing ampacity.

