


LightLEEDer Netlink Module Wiring Details



Wiring Information:

- The ribbon cable from the LLNetLink module connects to one of the 4 add-on serial ports on the LightLEEDer Network Controller (LLNC)
- The TCP-IP port connects to the LAN network with a CAT-5 cable.
- Power connects to the module from the 5VDC power supply with provided barrel connector.