

MODELS

MODEL #	PIR	ACOUSTIC	PHOTOCELL	LENS TYPE
ILC-SWX-201-2	•			SMALL MOTION
ILC-SWX-211-2	•		•	SMALL MOTION
ILC-SWX-221-2	•	•		SMALL MOTION
ILC-SWX-231-2	•	•	•	SMALL MOTION
ILC-SWX-202-2	•			LARGE MOTION
ILC-SWX-212-2	•		•	LARGE MOTION
ILC-SWX-222-2	•	•		LARGE MOTION
ILC-SWX-232-2	•	•	•	LARGE MOTION
ILC-SWX-203-2	•			HIGH BAY
ILC-SWX-213-2	•		•	HIGH BAY

ADDITIONAL UNIT OPTIONS

- **D:** Daylight Harvesting (0-10) - **HE:** High Humidity Environment

SPECIFICATIONS

ELECTRICAL

OPERATING VOLTAGE
MVOLT (120-277 VAC)

LOAD RATINGS
800W @ 120 VAC
1200W @ 277 VAC

LOAD TYPES
Tungsten
Ballast
LED

DIMMING CAPACITY (-D OPTION)
50mA

DIMMING COMPATIBILITY
0-10 VDC Ballasts or Drivers
Compliant with IEC 60929 Annex E.2

PHYSICAL

SIZE
4.00" Diameter x 1.25" H
(10.16 x 3.17 cm)

WEIGHT
4.75 oz

COLOR
White

ENVIRONMENTAL

OPERATING TEMP
32°F to 122°F (0°C to 50°C) -
Standard
-40° F/C (with **-HE** Option)

RELATIVE HUMIDITY
0-95% Non-Condensing,
Indoor Use Only

OPERATION

TIME DELAYS
30 sec to 30 min (Typical)
10 Minute Default

TEST MODE
5 sec Time Delay
Expires After 10 min

CODE COMPLIANCE

Sensors can be used to meet
ASHRAE 90.1, IECC, & Title 24
energy code requirements

OTHER

LISTINGS
UL/CUL

OVERVIEW

INTELLIGENT LIGHTING CONTROLS line voltage sensors detect movement in the infrared energy that radiates from occupants as they move within the devices field-of-view. Once occupancy is identified the sensor's internal relay switches power on to the connected lighting. If equipped with passive dual technology (PIR/Acoustic), the unit's microphone is then also enabled to further enhance detection while the lights are on. This overlapping passive acoustic occupancy detection is important for rooms with obstructions or where occupant motion will be limited. An internal timer is set to keep lights on during brief periods of inactivity, and is reset every time occupancy is signaled by either the passive infrared or acoustic detection technologies. Enhanced options for this sensor family include a photocell that will override lights off if sufficient ambient light is present and active daylight harvesting for 0-10V lighting.



FEATURES

- Digital Passive Infrared (PIR) Detection
- Passive Acoustic Detection (Optional)
- 360° Coverage Pattern
- Field Changeable Lens
- Compact Size and Matte Finish
- Convenient Test Mode and Adjustable Time Delays
- On/Off Photocell & 0-10V Daylight Harvesting (Optional)
- Electronically Timed Switching Designed for LED Fixture Control



SENSOR PLACEMENT

Typically, a sensor should be located such that all entrances to the room/space are adequately covered. Ideally, a sensor should be located so that its coverage beams are perpendicular to the door. This ensures that an occupant is detected immediately upon entering. See Diagram 1. Note, however, it is important to locate a sensor such that its coverage pattern can not extend through an open door, which could result in detection of persons walking by, but not into, a room.

If line of sight between a sensor and occupants is blocked (for example by a cubicle wall or stall), dual technology sensors should be alternatively utilized or additional PIR sensors should be added until line of sight is restored. Dual technology is recommended for all spaces where occupants are sitting or where motion within the space is limited (private offices, open offices, restrooms with stalls, libraries). Dual technology is not recommended for hallways or warehouses.




Diagram 1 - Recommended Sensor Placement in a Private Office


COVERAGE

PASSIVE INFRARED (PIR)

- 8 to 15 ft (2.44 to 4.57 m) mounting height recommended for small and large motion lenses. For 15 to 40 ft (2.44 to 12.20 m) mounting heights use high bay lens.
- Detection range improves when walking across beams as compared to into beams.
- Lenses can be swapped in field if necessary, contact technical support for assistance.


SMALL MOTION 360°

- Best choice for detection of small motions from sitting occupants (e.g., hand motion)
- ~500 ft² of coverage




LARGE MOTION 360°

- Best choice for detection of larger motion (e.g., walking)
- ~2000 ft² of coverage
- Longest segment of coverage pattern aligns with screw hole axis on sensor (shown as dotted line on Top View diagram below)



HIGH BAY 360°

- Best choice for mounting heights above 15ft
- Recommended for gyms, warehouses, and other high ceiling areas
- Not recommended for areas where occupants are sitting
- Gaps between outer segments get larger as mounting height increases
- Not available with acoustic (dual technology)




DUAL TECHNOLOGY (PIR/ACOUSTIC)

- Units with dual technology (e.g. ILC-SWX-221-2 and ILC-SWX-222-2) have overlapping acoustic detection of the complete PIR coverage area
- A PIR event is required to initially enable acoustic detection.
- Sounds indicating occupancy reset the sensor's time delay while non-occupant noises are filtered out.
- Occupant sounds alone will not keep lights on indefinitely, PIR motion must be periodically detected for lights to remain on for an extended time.
- After sensor time out expires, acoustic detection remains enabled for 15 seconds to enable voice reactivation of lights for additional convenience and safety.


WIRING

- Sensors can be wired in parallel, although the total switching load specification remains the same as it is for one sensor.
- When wired in parallel, both sensors must time out for connected lighting to turn off.
- If wiring in an additional toggle switch for override off control, connect between the sensor and the load.

SINGLE PHASE WIRING




2-PHASE WIRING (208 VAC)



DIMMING WIRING

- Dimming wires are present on daylight harvesting models with -D option



* VIO/GRY DIMMING WIRES (0-10V) SHOULD BE TREATED AS CLASS 1

INSTALLATION NOTES

For supply connections, use wires rated for at least 75°C or equivalent.




INSTALLATION OPTIONS

- Designed to mount to a mud ring w/ 2.75" spaced ears, screws provided.
- Also fits a 3.5" trade size octagon box.
- Note a 4.0" octagon box requires a mudring or a model #ILC-299 trim ring (see below diagrams).

BASIC MOUNTING OPTIONS


FRONT



- SCREW HOLES FOR DIRECTLY MOUNTING TO:
 - CEILING SURFACE
 - 3-1/2" (TRADE SIZE) OCTAGON BOX
 - MUD RING WITH 2-3/4" SPACED EARS

SIDE


3.5" TRADE SIZE OCTAGON JUNCTION BOX




SENSOR MOUNTED
DIRECTLY TO
3.5" TRADE SIZE
OCTAGON BOX

SIDE

4" JUNCTION BOX




ADDITIONAL MOUNTING OPTIONS USING ILC-SWX-299 TRIM RING




SIDE

4" OCTAGON BOX



4" HANDY BOX (or SINGLE GANG MUDRING)



GENERAL CONFIGURATION SETTINGS

FUNCTION #2 - TIME DELAY CONFIGURATION

The length of time after the last detected occupancy event that the sensor will stay in the occupied state.

CHANGING TIME DELAY SETTINGS:

1. Read through the Time Delay Settings list on the right and note the number of the desired time delay setting (e.g., default is 4 = 10 minutes).
2. Press and release the unit's pushbutton twice, then wait 2 seconds. The white LED will blink back the number of the current setting.
3. At any time after blink back starts, enter number of new setting (from Time Delay Settings table on right).
4. New setting is saved after white LED blinks new number back 3 times. If blue LED double flashes at any time, start process over.

FUNCTION #2 - TIME DELAY SETTINGS

SETTING #	DESCRIPTION
1	Test Mode*
2	30 sec
3	5 min
4	10 min (default)
5	15 min
6	20 min
7	30 min

* 5 SEC TIME DELAY, EXPIRES AFTER 10 MIN

EXTENDED TIME DELAYS**

SETTING #	DESCRIPTION
8	1 hr
9	2 hr
10	4 hr
11	8 hr

** EXTENDED TIME DELAYS GREATLY REDUCE ENERGY SAVINGS

FUNCTION #6 - MICROPHONE (ACOUSTIC DETECTION)

Dual technology sensors prevent non-occupant sounds from resetting the time delay by dynamically reducing the microphones sensitivity at specific frequencies. In some environments, decreasing the sensitivity across all frequencies so that lights go off sooner, may be preferred. A unit's microphone can also be disabled (effectively changing sensor to a PIR only version).

TO CHANGE MICROPHONE SETTINGS:

1. Press unit's pushbutton 6 times, then wait two seconds. The white LED will blink back the number of current setting (from table on right).
2. At any time after blink back starts, enter number of new setting by pressing the button equal times to choice from table on right.
3. New setting will be saved after white LED blinks back new number 3 times. If blue LED double flashes at any time, start process over.

FUNCTION #6 - MICROPHONE

SETTING #	DESCRIPTION
2	Normal Operation [default]
3	Reduced Sensitivity
4	Disabled

FUNCTION #7 - LED INDICATION

By default, the sensor blinks its white LED whenever it detects PIR motion. A unit with dual technology will also blink the LED white when it acoustically detects occupancy. The intensity of this LED can be increased or disabled. Additionally, the LED can be enabled to blink white for only PIR events and blue for an acoustic event.

CHANGING LED INDICATION SETTINGS:

1. Press unit's pushbutton 7 times, then wait two seconds. The white LED will blink back the number of current setting (from table on right).
2. At any time after blink back starts, enter new setting by pressing the button equal times to numbered choices.
3. New setting will be saved after white LED blinks back new number 3 times. If blue LED double flashes at any time, start process over.

FUNCTION #7 - LED INDICATION SETTINGS

SETTING #	DESCRIPTION
2	White LED for all occupancy, normal brightness (default)
3	White LED for all occupancy, increased brightness
4	Disable LED
5	White LED for PIR, blue for Acoustic, normal brightness
6	White LED for PIR, blue for Acoustic, increased brightness

DAYLIGHT HARVESTING & PHOTOCELL CONFIGURATION

Along with occupancy based control, units with an integrated photocell can provide on/off or inhibit-only control of lighting based on the amount of ambient light present. Units with the daylight harvesting option can also directly dim 0-10V lighting. See the model number table on page 1 for details on included features for each unit. Descriptions of modes are below.

DAYLIGHT HARVESTING

- Recommend for spaces where it is important to not distract occupants (e.g., offices, classrooms).
- Lights will gradually dim in order to maximize energy savings while maintaining desired overall lighting level.
- Option to dim to low trim or turn lighting off.

ON/OFF PHOTOCELL CONTROL

- Recommended for public spaces (hallways, entryways, etc) where fully switching of lighting off and on will not cause distraction of occupants.
- Lights are switched off if ambient light level surpasses threshold and back on if level drops.

INITIAL INHIBIT ONLY PHOTOCELL CONTROL

- Lighting is held off if sufficient ambient light level is present upon initial occupancy.
- Lighting will turn on if light level drops below setpoint.
- Once on, lighting will only turn off from vacancy or a manual switch, never from daylight.

DAYLIGHT HARVESTING & PHOTOCELL CONFIGURATION (CONT.)

FUNCTION #3 - PHOTOCELL & DIMMING OPERATIONAL MODES

To change the operation of the photocell and/or dimming output (in equipped units), use the following procedure:

CHANGING THE PHOTOCELL OPERATIONAL MODE:

1. Press and release the unit's pushbutton 3 times, then wait 2 seconds. The white LED will blink back the number of the current setting (repeats 3 times before exiting).
2. At any time after blink back starts, enter number of new setting from table on right (e.g., 3 for Occupancy + Daylight Harvesting to Off).
3. New setting is saved after white LED blinks back new number 3 times. If blue LED double flashes at any time, new setting was not saved and process must be repeated.

ON ON/OFF PHOTOCELL OPERATION NOTES

- During periods of occupancy, when the measured light level is high enough for 5 min. such that turning the lights off will not drop the level below the selected setpoint, the sensor will turn connected lighting off.
- During this 5 min. transition time the LED will blink blue at 0.5 second intervals.
- After lights are turned off, the sensor's LED double blinks blue every 15 seconds as an indication that sufficient ambient light is the reason the lights are being held off.
- If the ambient light level falls below the setpoint for more than 30 seconds, lights will switch back on. During this transition time the LED also will blink blue at 0.5 second intervals.

FUNCTION #4 - PHOTOCELL SETPOINT


The minimum overall light level that is to be maintained in a space by the sensor is referred to as the "setpoint". This value is user selectable or can be chosen by the Auto-Setpoint function that is built into the sensor.

SETPOINT CONFIGURATION

1. Read through the below setpoint values list and note the number of the desired setpoint (e.g., default is 7 = 25 fc).
2. Press and release the unit's pushbutton 4 times, then wait 2 seconds. The LED will blink back the value of the current setting in two alternating digits:
Blue LED = 10's digit (1-12 blinks or rapid blink for 0)
White LED = 1's digit (1-9 blinks or rapid blink for 0)
3. At any time after blinking starts, enter number of new setting (from Setpoint Value Table).
4. New setting is saved after white LED blinks new setting back 3 times. If blue LED double flashes at any time, an error condition exists and process must be repeated.

FUNCTION #4 - SETPOINT VALUE TABLE

SETTING #	DESCRIPTION
2	Run Auto-Setpoint*
3	2.5 fc
4	5.0 fc
5	10.0 fc
6	15.0 fc
7	25 fc (default)
8	35 fc
9	50 fc
10	75 fc
11	100 fc



FUNCTION #3 - PHOTOCELL OPERATIONAL MODES

SETTING #	DESCRIPTION	MODEL # NOTES
2	Occupancy + On/Off Photocell Control (Photocell Enabled)	Default for ILC-SWX-21x-2 & ILC-SWX-23x-2. See on/off operation notes below.
3	Occupancy + Daylight Harvesting to Off Photocell Control (Photocell Enabled)	Default for ILC-SWX-21x-2-D & ILC-SWX-23x-2-D. See on/off operation notes below.
4	Occupancy + Initial Inhibit Photocell Control (Photocell Enabled)	
5	Occupancy only (Photocell Disabled)	Default for ILC-SWX-20x-2 & ILC-SWX-22x-2
6	Occupancy + Daylight Harvesting to Low Trim (Photocell Enabled)	
7	Occupancy - High/Low (Photocell Disabled)	Lights will drop to low trim after occupancy time delay expires.
8	Occupancy - High/Low/Off (Photocell Disabled)	Lights will drop to low trim after occupancy time delay expires, then turn off after secondary time delay expires.

*AUTO-SETPOINT SELECTION DETAILS

- A Once setting 2 "Run Auto-Setpoint" has been selected (by following above steps 1-4), the sensor's LED will alternate blue and white for 30 seconds. During this time user should move away from sensor.
- B Lights will then be cycled in order for sensor to calculate the controlled (artificial) light level. This is done by subtracting the light level with the lights off (relay open) from the light level with the lights on (relay closed).
- C A setpoint will then be chosen using the following conditions:
 - If controlled level is less than 3 fc, the application is considered open loop and the setpoint will be set to 25 fc.
 - If controlled level is between 3 and 100 fc, setpoint will be set to that level times 1.25.
 - If controlled level is greater than 100 fc the setpoint will be set to 125 fc.
- D Unit will immediately start operating with new setpoint (i.e. blue LED may begin flashing indicating it will transition lights soon)
- E To check auto selected setpoint, press and release button 4 times. Setpoint will be blinked back in two alternating digits:
Blue LED = 10's digit (1-9 blinks or rapid blink or 0)
White LED = 1's digit (1-9 blinks or rapid blink or 0)

DIMMING CONFIGURATION SETTINGS

CHANGING DETAILED DIMMING SETTINGS

The settings listed in the below function tables can be adjusted using the following programming procedure.

- 1 From the below tables of detailed functions, note the number (#) of the function to be modified. For example, the **HIGH TRIM** setting is #9.
- 3 To access a particular function, press and release the programming button the number of time of the chosen function. For example, press the button 9 times to access the **HIGH TRIM** function.
- 4 The LED will flash back white the setting number of the current value as it appears in each function's detailed table below. For example, the default **HIGH TRIM** is setting #2 (10V)
- 5 To change the setting number, press and release the button the number of times equal to the new setting #. For example, 3 times (for 9V).
- 6 The LED will flash back white the new setting number as confirmation and will be saved after three confirmations. If LED double flashes blue at any time, start process over.

DETAILED DIMMING FUNCTION TABLES

FUNCTION #5 - TURN OFF SCHEME

The method by which a sensor with daylight harvesting (dimming) turns off connected lighting.

SETTING #	VALUES	NOTES
2	Drop to Off	Dimming output drops to low trim level & relay opens.
3	Fade to Off (default)	Dimming output fades to low trim & relay opens.
4	Fade to 0V	Dimming output fades to low trim level and then drops to 0 volts (e.g. below a connected driver's electronic off level). Unit's relay remains closed.
5	Fade to Low Trim	Dimming output fades down to low trim level. Unit's relay remains closed.
6	Drop to Low Trim	Dimming output drops down to low trim level. Unit's relay remains closed.
7	Drop to 0V	Dimming output drops to 0 volts (e.g. below a connected driver's electronic off level. Unit's relay remains closed.

FUNCTION #9 - HIGH TRIM

The maximum voltage to which the sensor is allowed to raise its dimming output in the full bright state.

SETTING #	VALUES	NOTES
2	~10 VDC (default)	Light output at each voltage level depends on driver/ballast and luminaire.
3	~9 VDC	
4	~8 VDC	
5	~7 VDC	
6	~6 VDC	
7	~5 VDC	

FUNCTION #10 - LOW TRIM

The minimum voltage to which the sensor is allowed to reduce its dimming output when measuring high levels of ambient light (or when unoccupied in an Occupancy - High/Low operational mode).

SETTING #	VALUES	NOTES
2	~0 VDC	Light output at each voltage level depends on driver/ballast and luminaire.
3	~1 VDC	
4	~2 VDC	
5	~3 VDC (default)	
6	~4 VDC	
7	~5 VDC	

FUNCTION #11 - FADE OFF TIME

Adjustable time interval for lights to ramp down to off (or low trim).

SETTING #	VALUES
2	0.75 Sec
3	1.5 Sec (default)
4	3 Sec
5	5 Sec
6	15 Sec
7	Disabled

FUNCTION #12 - FADE ON TIME

Adjustable time interval for lights to ramp up when sensor is in the occupied state.

SETTING #	VALUES
2	0.75 Sec
3	1.5 Sec (default)
4	3 Sec
5	5 Sec
6	15 Sec
7	Disabled

FUNCTION #13 - SECONDARY TIME DELAY

For sensors in Occupancy - High/Low/Off operational mode, the amount of time the dimming voltage will stay at the low trim level before turning the lights completely off (assuming space remains unoccupied).

SETTING #	DESCRIPTION
2	0 Sec
3	30 Sec
4	2.5 Minutes
5	5 Minutes* (default)
6	10 Minutes

TESTING & TROUBLESHOOTING

TEST MODE

A test mode with a 5 second time delay is provided in order to efficiently perform walk testing. The sensor will blink white on a detected PIR event and blue on detected Acoustic event, although its time delay will only be reset by a PIR event. Note that while in test mode all LED activity related to ambient light override (photocell) functionality is overridden.

TO PUT A SENSOR IN TEST MODE FOR 10 MINUTES:

- Press sensor's pushbutton 2 times, then wait two seconds
- Press button 1 time to start test mode. After 10 minutes, the sensor's time delay will revert to previous setting

PHOTOCELL MOUNTING

Do not mount sensor such that it is directly viewing into the lights it is controlling. This will cause the measured level of controlled/artificial light to be extremely high, thus preventing the sensor from ever turning lights off from ambient light.

FACTORY RESET

To restore factory settings, press and release the pushbutton 8 times, wait 2 seconds, then press and release the pushbutton 3 times again. The unit will flash back 3 sets of 3 white blinks followed by a rapid double flash indicating a successful reset.