

LightLEEDer-EVO-4X, -8X Mapping

Address Switch Settings	A		A - B	
	EVO-4X Relays	EVO-4X Dimmers	EVO-8X Relays	EVO-8X Dimmers
1	RLY 01 to 04	DIM 01.1 to 4	RLY 01 to 08	DIM: 01.1 to 4, 02.1 to 4
2	RLY 05 to 08	DIM 02.1 to 4	RLY 05 to 12	DIM 02.1 to 4, 03.1 to 4
3	RLY 09 to 12	DIM 03.1 to 4	RLY 09 to 16	DIM 03.1 to 4, 04.1 to 4
4	RLY 13 to 16	DIM 04.1 to 4	RLY 13 to 20	DIM 04.1 to 4, 05.1 to 4
5	RLY 16 to 20	DIM 05.1 to 4	RLY 16 to 24	DIM 05.1 to 4, 06.1 to 4
6	RLY 21 to 24	DIM 06.1 to 4	RLY 21 to 28	DIM 06.1 to 4, 07.1 to 4
7	RLY 25 to 28	DIM 07.1 to 4	RLY 25 to 32	DIM 07.1 to 4, 08.1 to 4
8	RLY 29 to 32	DIM 08.1 to 4	RLY 29 to 36	DIM 08.1 to 4, 09.1 to 4
9	RLY 33 to 36	DIM 09.1 to 4	RLY 33 to 40	DIM 09.1 to 4, 0A.1 to 4
A	RLY 37 to 40	DIM 0A.1 to 4	RLY 37 to 44	DIM 0A.1 to 4, 0B.1 to 4
B	RLY 41 to 44	DIM 0B.1 to 4	RLY 41 to 48	DIM 0B.1 to 4, 0C.1 to 4
C	RLY 45 to 48	DIM 0C.1 to 4	RLY 45 to 52	DIM 0C.1 to 4, 0D.1 to 4
D	RLY 49 to 52	DIM 0D.1 to 4	RLY 49 to 56	DIM 0D.1 to 4, 0E.1 to 4
E	RLY 53 to 56	DIM 0E.1 to 4	RLY 53 to 60	DIM 0E.1 to 4, 0F.1 to 4
F	RLY 57 to 60	DIM 0F.1 to 4	RLY 57 to 64	DIM 0F.1 to 4, 10.1 to 4
O	RLY 61 to 64	DIM 10.1 to 4	Invalid	Invalid

Modules are factory built as a 4X or 8X controller. Refer to the columns for the device supplied.